





OPERATING INSTRUCTIONS

LOAD CARRIER

Building material



515133256-00 EN

Dear Customer,

These are the operating instructions for the KRONE vehicle you have purchased.

These operating instructions contain important information for the proper use and safe operation of the KRONE vehicle.

If these operating instructions should become completely or partially unusable for any reason, you can order replacement operating instructions for your KRONE vehicle by stating the item number.

Customer Service

Telephone: +49 (0) 59 51 / 209-320

Fax: +49 (0) 59 51 / 209-367

email: kd.nfz@krone.de

Spare Parts

Telephone: +49 (0) 59 51 / 209-302

Fax: +49 (0) 59 51 / 209-238

email: Ersatzteile.nfz@krone.de

Table of contents

1	Information about this document.....	7
1.1	Introduction	7
1.2	Other applicable documents	7
1.3	Product identification and type plate	7
1.4	Retention of documents	8
1.5	Part positions	8
1.6	Optional components	8
1.7	Symbols used in these instructions	8
1.8	Copyright	9
2	Safety	10
2.1	Warnings.....	10
2.2	Intended use	10
2.3	Personnel qualification and requirements.....	11
2.3.1	Operator.....	11
2.3.2	Driving staff.....	11
2.3.3	Skilled craftsmen	11
2.4	Personal protective equipment	12
2.5	Transported material characteristics.....	12
2.6	Information, warning, and mandatory signs	12
2.7	Danger areas	12
2.8	Protective and safety devices	12
2.9	General safety instructions	13
2.10	Notes about legal regulations	14
2.11	Warranty and liability	15
2.12	Limits of use.....	15
2.13	Environmental hazards	15
3	Vehicle overview.....	17
4	Commissioning.....	19
4.1	Initial commissioning.....	19
4.2	Delivery and handover	19
5	Running gear operation	20
5.1	Using wheel chocks	20
5.1.1	Wheel chocks without anti-theft device.....	20
5.1.2	Wheel chocks with anti-theft device.....	20
5.1.3	Wheel chocks with spring-clip mount.....	20

5.1.4	Putting on the wheel chocks	21
5.2	Landing leg winches	21
5.3	Rear braces	23
5.3.1	Rear braces with crank mechanism (rigid)	23
5.3.2	Rear braces without crank mechanism.....	24
5.4	Draw fork	25
5.5	Drawbar wale.....	28
5.6	Supply and control connections.....	29
5.7	Blind couplings.....	32
5.8	Draining the compressed air tanks	33
5.9	Brake system	33
5.9.1	Service brake.....	35
5.9.2	Parking brake.....	35
5.9.3	Emergency release devices for the parking brake.....	36
5.10	Air suspension	39
5.11	Lift axles.....	41
5.12	Rigid axle	42
5.13	Step-on devices	42
5.13.1	Hand strap	42
5.13.2	Aluminium ladder	42
5.13.3	Fold-down steps	43
5.14	Side collision protection	43
5.14.1	Folding side collision protection with lock.....	43
5.15	Spare wheel bracket	44
5.15.1	Spare wheel with basket storage.....	45
5.15.2	Spare wheel with winch	45
5.15.3	Spare wheel in the pallet storage box.....	46
5.15.4	Changing the spare wheel	46
5.16	Storage box	47
5.17	Pallet storage box	48
5.18	Depots	49
5.18.1	Post depot.....	49
5.18.2	Bracket for Multi Block beams	50
5.19	Tool box	50
5.20	Water tank	51
5.21	Fire extinguisher	51
6	Superstructure operation.....	53
6.1	Board walls and posts.....	53
6.2	Rear wall.....	55
6.3	Door retainer chain	57

6.4	Mobile front wall.....	57
6.5	Front wall depot for edge protectors	58
7	Road operations	60
7.1	Commissioning before each trip	60
7.2	Hitching and unhitching the trailer	60
7.3	Manoeuvring the trailer without a connected compressed air supply	63
7.4	Parking the trailer safely	64
8	Loading and securing	65
8.1	Using straps	66
8.2	Ensuring form-fitting.....	68
8.3	Securing pallets with hoop casings and shrink-wrap	68
8.4	Securing loads with tension chains to centre posts/board walls.....	68
8.5	Using the Multi Safe system	69
8.5.1	Using the Multi-Lock external frame	69
8.5.2	Using the Multi Lash lashing rings	69
8.5.3	Using the Multi Flex chain adapter	70
8.5.4	Using the Multi Flex Flat chain adapter	70
8.5.5	Using the Multi Fix system.....	71
8.5.6	Multi Rail lashing rail.....	72
9	Troubleshooting in the event of faults	73
9.1	Checking the lift axle control.....	74
9.2	Fixing braking abnormalities	74
10	Maintenance and repair.....	77
10.1	Care and cleaning.....	77
10.2	Maintenance	78
10.2.1	Regular checks and functional testing	79
10.2.2	Maintenance intervals for the authorised specialist workshop.....	80
10.2.3	Maintenance intervals for the driver.....	81
10.2.4	Wheels and tyres	81
10.2.5	Axle and suspension.....	81
10.2.6	Brake system.....	82
10.2.7	Lubricating the trailer	83
10.2.8	Electrical equipment	83
10.2.9	Contour marking	83
10.2.10	Bolted connections	83
10.2.11	Load securing	83
10.2.12	Coupling ring.....	83
10.2.13	Tail lift batteries.....	83
10.3	Repair	84
11	Decommissioning.....	86

11.1	Temporary decommissioning.....	86
11.2	Recommissioning	86
11.3	Final decommissioning and disposal	87
12	Spare parts and customer service	88
12.1	Spare parts	88
12.2	Customer service and support.....	88
13	Technical data.....	89
13.1	Dimensions and weights.....	89
13.2	Plugs and socket pin assignments	89
13.2.1	Connector	89
13.2.2	Socket S (white) ISO 3731, 7-pin	89
13.2.3	Socket N (black) ISO 1185, 7-pin	90
13.2.4	Socket ISO 12098, 15-pin.....	90
	Index	91

1 Information about this document

1.1 Introduction

These operating instructions are intended for the operators of the trailer and their staff. The operating instructions are designed to help you to get to know the trailer and to use it within its intended usage capabilities.

It is mandatory that the operating instructions be read, understood and applied by every person who is tasked with the following work:

- Driving, parking and manoeuvring the trailer,
- Loading and unloading the trailer,
- Resolving any disruptions to the workflow,
- Servicing the trailer (maintenance and care),
- Disposing of working materials and auxiliary materials.

The operation instructions incorporate important hints for safe, appropriate, and economical operation of the trailer. They serve to

- prevent risks and damages,
- reduce repair costs and downtimes, and
- increase the reliability and durability of the trailer.

Immediately replace operating instructions that have become illegible or are missing.

KRONE cannot be held liable for damage and operational interference caused by failure to observe these operating instructions.

The warranty conditions can be found in our general terms and conditions of business.

INFO

If you have any questions, please contact KRONE customer service (see "12.2 Customer service and support", pg. 88).

1.2 Other applicable documents

For safe and failure-free operation of the trailer, detailed knowledge of the individual components is required. Other documents also apply in conjunction with these operating instructions.

Please observe the following additional documents, especially the safety instructions:

- Operating instructions for the tractor unit,
- All instructions for additional parts and components,
- All instructions for additional equipment and special equipment.
- Re-order any instructions that have gone missing or become illegible (see "12 Spare parts and customer service", pg. 88).

When handling the trailer and for all maintenance work, please also observe:

- The maintenance regulations for the used installed components,
- Load securing regulations.

1.3 Product identification and type plate

Every trailer can be clearly identified by the attached type plate. The vehicle ID number (VIN) is also embossed on the chassis.

The type plate is attached to the following location for product identification:




Fig. 1-1: Type plate attachment points

- 1 Standard
- 2 Alternative

The following information is shown on the type plate:




Fig. 1-2: Example type plate

- 1 Manufacturer
- 2 EC type approval number (if available)
- 3 Vehicle ID number
- 4 Approved total mass
- 5 Total mass on the coupling point
- 6 Technically approved axle loads
- 7 Technically approved total mass

- 8 If applicable, the nationally approved total masses for registration/operation including the code
- 9 If applicable, dead weight
- 10 Min. distance
- 11 Distance/max. distance
- 12 Vehicle width
- 13 Vehicle length
- 14 If applicable, national type approval no.
- 15 Type designation

1.4 Retention of documents

- ▶ Store these instructions and all other applicable documents in a safe place.
- ▶ Pass the complete documentation on to the next driver or owner.

1.5 Part positions

The description of part positions is always viewed in forward driving direction.

1.6 Optional components

KRONE trailers are fitted with a number of optional components. The operating instructions describe all of the components in the following sections.

All the components are not necessarily on your trailer.

1.7 Symbols used in these instructions

Various markings and symbols are used in the text in these instructions. These are explained below.

- Bullet list
 - Sub-list
- 1. Numbered list
- ☑ Prerequisite for action
- ▶ Action step
 - ⇒ Intermediate action result
- ✓ Result of the action

INFO
Additional information and tips.

 : Also observe the enclosed supplier documentation.

1.8 Copyright

These instructions represent an official document within the meaning of laws against unfair competition. They incorporate texts and drawings which, in their entirety or partly, without written consent of the manufacturer, are not to be

- copied (except attached copy originals),
- published, or
- made public by other means.

The copyright to these instructions remains with

Fahrzeugwerk Bernard KRONE
GmbH & Co. KG, D-49757 Werlte

Violations oblige compensation for damages.

2 Safety

This manual contains instructions for your safety and for safe operation.

The basic safety instructions include instructions that apply fundamentally to safe use or maintenance of the safe condition of the trailer.

The action-related warnings warn you about residual hazards and are found before a dangerous action.

- ▶ Follow all the instructions to prevent personal injury, environmental or property damage.

2.1 Warnings

Design and structure

The action-related warnings are structured as follows:

⚠ WARNING
Type and source of the danger!
Explanation of the type and source of the danger.
▶ Measures to avert the danger.

Hazard level

The warnings are classified according to the severity of the danger. The following explains the danger levels with their associated signal words and warning symbols.

⚠ DANGER
Direct danger to life or serious injuries

⚠ WARNING
Possible danger to life or serious injuries

⚠ CAUTION
Possible slight injuries, environmental damage or property damage

⚠ WARNING
Possible serious injury caused by crushing

⚠ CAUTION
Possible slight injury caused by crushing

NOTE
Possible environmental damage or property damage

2.2 Intended use

Intended use includes the observance of all operating and maintenance instructions supplied with the vehicle as well as the observance of the maintenance intervals and conditions prescribed therein.

The KRONE trailer and its superstructures are intended exclusively for legal transportation purposes in compliance with applicable laws, rules and regulations.

Operational reliability of the vehicle is guaranteed only if all applicable instructions, settings, laws, rules, regulations, and limitations are fully complied with.

The trailer is produced with state-of-the-art manufacturing systems in compliance with all applicable safety-related laws, rules, and regulations. Nevertheless, operation of the trailer incorporates dangers for life and limb of the operator and other personnel, or danger of equipment damage, or operational problems.

- ▶ The trailer is to be operated only if in technically adequate state, and in accordance with safety and danger-related laws, rules, and regulations, under strict compliance with the operation instructions.
- ▶ Have any faults that could impair safety immediately repaired by an authorised specialist workshop.

Foreseeable misuse

Any use going beyond proper transport usage is considered non-intended. Avoid the following:

- Transport of persons or animals
- Transports that are subject to special regulations, e.g. dangerous goods transports

- Transport of unsecured loads
- Transport of materials, which, due to their properties, do not ensure safe handling and transport or only with additional equipment
- Exceeding the technically permitted weights, axle loads and drawbar loads
- Exceeding the maximum vehicle speed
- Exceeding the permitted length, width and height dimensions (including by driving with an expanded rear)
- Use of components that are not approved by KRONE, e.g. tyres, accessories, spare parts

Fahrzeugwerk Bernard KRONE GmbH & Co. KG is not liable for damage resulting from non-intended use. Risks deriving from such infractions are exclusively borne by the operator.

2.3 Personnel qualification and requirements

KRONE trailers and KRONE superstructures as well as their operating components may only be used and maintained by persons who have the respective qualification and who have read and understood the operating instructions.

In the operating instructions, a distinction is made between

- Operator,
- Driving staff, and
- Skilled craftsmen.

2.3.1 Operator

The operator is responsible for proper operation of the vehicle. The operator must:

- Instruct the driving staff in the use of the vehicle,
- Ensure that the trailer is regularly checked and serviced in an authorised technical workshop.

2.3.2 Driving staff

The driving staff consists fundamentally of the vehicle driver and a co-driver if applicable. The driving staff are responsible for proper operation of the vehicle and must

- Have read and understood the operating instructions,
- Have reached the legal minimum age.
- Ensure that the trailer is regularly serviced by qualified staff.

When transporting and loading/unloading, only driving staff may be used who have received instruction prior to the first deployment and who have subsequently received verbal instruction at least once a year relating to this work.

This instruction should particularly cover the following points:

- The operating instructions,
- The measures to be taken in the event of malfunctions.

Driving is limited to persons who have the required driving license. In addition, the drivers must receive training with respect to:

- The respective transport trailer and associated tractor unit,
- The additional suppliers' information listed (*see "1.2 Other applicable documents", pg. 7*),
- Motor Vehicle Traffic Regulations and Motor Vehicle Construction and Use Regulation, C.U.R., and
- All relevant regulations that apply to health and safety, accident prevention and environmental protection in the country of use, as well as
- Other safety-related, occupational health and road traffic regulations.

2.3.3 Skilled craftsmen

The skilled craftsmen of a specialist workshop are authorised to perform the maintenance work (maintenance and repair). Authorised skilled craftsmen must have a recognised qualification or have the relev-

ant knowledge of their specialised area required to meet the relevant regulations, rules and guidelines.

2.4 Personal protective equipment

Personal protective equipment serves to avoid injuries and is prescribed by national regulations depending on the cargo.

- ▶ Wear suitable personal protective equipment when loading and unloading.
 - Depending on the transported goods, eyes, ears and respiratory tract must be protected with suitable protective equipment.
 - Gloves and safety shoes are generally worn.
- ▶ Observe the national regulations regarding personal protective equipment.
- ▶ Always keep an eyewash bottle filled with clean water at hand in the working environment.

2.5 Transported material characteristics

The trailer is designed to transport many different goods.

- ▶ Before loading, make sure that the trailer is suitable for the goods to be carried.

2.6 Information, warning, and mandatory signs

There are information, warning and mandatory signs attached to the trailer.

- ▶ Observe and follow the signs.
- ▶ Keep the signs clean and legible.
- ▶ Do not remove, paint over or paste over the signs.
- ▶ Immediately replace signs that have become illegible or are missing.

Depending on the equipment and use, appropriate pictograms are used in the information, warning and mandatory signs.

2.7 Danger areas

On and around the trailer there are areas with an increased danger to your safety or to the safety of other persons. Ensure adequate lighting when performing any work in hazard areas.

- ▶ Observe the following danger areas and instruct unauthorised persons to leave these areas:

Danger area	Danger
Loading and unloading area	There is a risk of injury on loose or uneven ground or on slopes.
Between the vehicle frame and the load	There is a risk of crushing.
Area approx. 5 m around the vehicle (manoeuvring area)	There is a risk of accidents.
Under the vehicle	The vehicle can move due to a defect or when starting up and injure persons.
Between the tractor unit and trailer, especially when hitching and unhitching	Persons can be crushed or run over. The trailer can tip over or tilt up.
Connection between the tractor unit and trailer	There is a risk of injury when hitching and unhitching the trailer from the tractor unit by incorrect operation when opening and closing the connections of the compressed air hose connectors and cables.

2.8 Protective and safety devices

Depending on the equipment, the trailers are equipped with the following protective and safety devices.

- ▶ Check the function of the protective and safety devices regularly.

- ▶ Have defective components repaired only by authorised specialist workshops or by KRONE.

Component	Function
Automatic anti-blockage system (ABS)	Prevents blockage of the wheels when braking
Automatic load-dependent brake power regulation (ALB)	Regulates the braking effect depending on the load status
Electronic brake system (EBS)	Braking assistance system, which contains/comprises the brake components and connected driving dynamics systems of the vehicle
Roll stability support (RSS)	Prevents the trailer from tipping over
Hazard lights	Serve to indicate a traffic hazard
Wheel chocks	Prevent accidental rolling away when parking/unhitching
Side collision protection	Prevents cyclists and pedestrians from passing under the trailer in case of accident
Underrun protection	Prevents under-running in case of rear-end collisions
Indicators and control displays	Serve to monitor and make settings for the trailer; optional systems differ according to the manufacturer

2.9 General safety instructions

The basic safety instructions include all safety measures sorted according to the theme, and must always be observed.

Pneumatic dangers

There is a risk of injury due to pressure in the pneumatic system.

- ▶ Do not open any components of the pneumatic system if there is pressure in the lines.
- ▶ Check the hose connections of the pneumatic system regularly.
- ▶ When aerating and venting the system, pay attention to unforeseeable movement of pneumatic actuators.
- ▶ Fully depressurise the pneumatic system before beginning maintenance work.

Dangers while driving

There is a risk of impact on bridges, in tunnels or with other structures. Persons can be injured or the vehicle, the transported goods, and the structure can be severely damaged.

- ▶ Observe the vehicle dimensions incl. the transported goods.
- ▶ Observe the permissible passage dimensions (height, width).

Dangers when manoeuvring, coupling and uncoupling

When manoeuvring or hitching and unhitching, there is a lethal risk of crushing for persons standing between the tractor unit and trailer as well as in the coupling area.

- ▶ Only drive in reverse when nobody is endangered.
- ▶ Only manoeuvre with a guiding assistant.
- ▶ Before uncoupling, secure the trailer additionally with wheel chocks against accidental movement.
- ▶ Instruct all persons to leave the area between the tractor unit and the trailer during the coupling procedure.

Dangers when parking and unhitching

Accidental trailer movements, unstable ground and poor securing at night can cause serious accidents and injuries.

- ▶ Actuate the parking brake when unhitching.

- ▶ Also use wheel chocks on the wheels.
- ▶ When parking the trailer in a public traffic area during the hours of darkness, the vehicle should be particularly marked in accordance with the legal requirements.

Load distribution

Incorrect load distribution as well as improperly secured loads can lead to dangerous road handling and serious accidents or damage to the vehicle.

INFO

Observe the load distribution plan for optimum loading. The load distribution plan is individually calculated for every trailer. Using the load distribution curve, you can read the distance that must be maintained between the front wall and the load.

- ▶ Observe the specified axle loads and drawbar loads.
- ▶ Secure the load in accordance with the applicable regulations.
- ▶ Ensure that the load securing aids are not damaged and are functional.

Load securing

Unsecured or incorrectly secured loads can result in poor road handling or even accidents. Lost loads can cause injury to other road users.

- ▶ Secure the load according to the requirements of the relevant regulations for load securing.
- ▶ Observe the instructions on the load securing certificates.

Dangers caused by improper maintenance

Improperly performed maintenance work (care and cleaning, maintenance, repairs) impairs the safety.

- ▶ Perform regular inspections for defects.
- ▶ Perform care and cleaning work properly.

- ▶ Only have repair work carried out by authorised specialist workshops or by KRONE.

Operating materials

Operating materials (e.g. lubricants, coolants, fuels) are hazardous to health. Immediately seek medical attention upon ingesting operating materials. If possible, avoid breathing vapours. Do not allow operating materials to come into contact with the skin, eyes, or clothing. Clean affected skin areas with water and soap. If it enters the eyes, immediately and thoroughly clean them with abundant clear water. Change soiled clothing as soon as possible. Keep operating materials away from children.

2.10 Notes about legal regulations

The trailer is built according to the regulations that were applicable at the time of delivery in the intended country of registration.

- ▶ Observe compliance with the nationally prescribed monitoring inspections and time intervals.
- ▶ Observe compliance with the nationally prescribed weights, axle loads, and drawbar loads. They can be lower than the technically possible values.
- ▶ Observe compliance with the nationally prescribed maximum vehicle height for the tractor-trailer combination.

Changes to the vehicle against the data provided in the registration documents result in the operating permit becoming invalid. This includes, in particular, driving on public roads without a power supply for the brake electronics via the ISO-7638 plug connection.

- ▶ Do not make any unauthorised changes or manipulations.
- ▶ Have permitted changes entered into the vehicle documentation by a certified test centre.

- ▶ Only use proper and approved tyres.
- ▶ Only used approved and suitable spare parts (see "12.1 Spare parts", pg. 88).
- ▶ Observe the normal use position of a moving component for normal vehicle use and when the vehicle is parked.
- ▶ Only drive with the EBS plug connected.
- ▶ Moving parts are to be positioned in the normal use position while driving, when stopped and parked:
 - Improper use (see "2.2 Intended use", pg. 10),
 - Operating the trailer with missing or non-functional safety devices,
 - Failure to observe the instructions, requirements and prohibitions of these operating instructions and the operating instructions for the accessories,
 - Failure to follow the instructions, requirements and prohibitions of the maintenance instructions,
 - Unauthorised structural changes to the KRONE product,
 - Inadequate monitoring of wear parts,
 - Improper maintenance or repairs not being carried out in good time,
 - Use of non-approved and unsuitable spare parts (see "12.1 Spare parts", pg. 88).

Component	Use position
Side collision protection (collision protection, pallet storage boxes, etc.)	Stow box covers at the side perpendicular and parallel to the vehicle's longitudinal axis are closed
Rear underrun protection	Lowest distance to the road
Spray suppression (spray suppression and splash guard)	folded down
Lighting equipment (spotlights, lights, lamps, signal devices and conspicuous markings) on curtains, board walls and rear doors	Corresponding to the delivery condition of the vehicle If curtains, board walls and/or rear doors with attached lighting equipment have been removed, the lighting equipment must be mounted to the vehicle again.

2.11 Warranty and liability

The "General terms and conditions of sale and delivery" from Fahrzeugwerk Bernard KRONE GmbH & Co. KG fundamentally apply.

Warranty and liability claims for personal injury and material damage are excluded if they are due to one of more of the following causes:

For the assessment of warranty and liability claims, you must permit unimpeded access to the data stored in the brake electronics. Deleting this data needed for an assessment can result in an exclusion of liability.

You can find the warranty conditions at www.krone-trailer.com.

2.12 Limits of use

- ▶ Observe the following requirements for the operational environment and conditions of use:
 - Permissible temperature range (depending on the specification, the additional equipment, and the tyres).
 - Permissible functional range and permissible age of the tyres
 - Permissible clearance and permissible swing radius
 - Load-bearing and level road conditions

2.13 Environmental hazards

- ▶ Always observe environmental protection when operating.
- ▶ Avoid the release of operating materials into nature and the environment.

SAFETY

- ▶ Dispose of operating materials and other chemicals in accordance with the applicable national regulations.
- ▶ Drive with the correct tyre inflation pressure.

3 Vehicle overview

The following illustrations provide an example for the superstructure of the turnframe trailer and the central axle trailer in the building material version with board walls.




Fig. 3-1: Overview of the turnframe version of the Load Carrier building material trailer

- 1 Board wall
- 2 Rear wall
- 3 Rear underrun protection
- 4 Axle assembly
- 5 Side collision protection
- 6 Control unit for brake system/air suspension
- 7 Draw fork




Fig. 3-2: Overview of the central axle version of the Load Carrier building material trailer

- 1 Board wall
- 2 Rear wall
- 3 Rear underrun protection
- 4 Tool box (option)
- 5 Axle assembly
- 6 Control unit for brake system/air suspension
- 7 Side collision protection
- 8 Drawbar wale

Usage designs

The Load Carrier building material trailer is intended for transporting building materials. It is designed as a turnframe trailer or as a central axle trailer. The trailer is offered with board walls or as a plateau.

4 Commissioning

4.1 Initial commissioning

Initial commissioning is performed by Fahrzeugwerk Bernard KRONE GmbH & Co. KG. The delivery from the factory or production site is ready for operation.

- ▶ Check that the documentation provided is complete.
- ▶ Obtain instruction on operation and ask questions if necessary.

INFO
The transfer is not done by staff from Fahrzeugwerk Bernard KRONE GmbH & Co. KG.

4.2 Delivery and handover

Delivery and handover of the trailer takes place at a production site of Fahrzeugwerk Bernard KRONE GmbH & Co. KG.

- ▶ Check that the documentation provided is complete.
- ▶ Familiarise yourself with the product and the documents.
- ▶ Obtain instruction on operation and ask questions if necessary.
- ▶ Collect with a suitable tractor unit.

5 Running gear operation

5.1 Using wheel chocks

WARNING

Risk of accident due to improperly used wheel chocks!

Unintentional trailer movements and improper use of wheel chocks can result in serious injury and property damage.

- ▶ Secure the tractor unit additionally with wheel chocks when unhitching.
- ▶ Secure the unhitched trailer with wheel chocks.
- ▶ Place wheel chocks only on wheels mounted on rigid axles, never on wheels mounted on lift axles or steering axles.
- ▶ Always secure wheel chocks on the trailer with the appropriate securing devices before travel.

5.1.1 Wheel chocks without anti-theft device

Removing the wheel chocks

- ▶ Remove safety split pin.
 - ▶ Pull the wheel chocks off the retaining rod.
- ✓ The wheel chocks have been removed.

Stowing the wheel chocks

- ▶ Slide the wheel chocks onto the retaining bar.
 - ▶ Secure the wheel chocks with the safety split pins.
- ✓ The wheel chocks are stowed and secured.

5.1.2 Wheel chocks with anti-theft device

Removing the wheel chocks

- ▶ Remove safety split pin.

- ▶ Pull out the wheel chocks with the theft protection chains.
- ✓ The wheel chocks have been removed.

Stowing the wheel chocks

- ▶ Insert the wheel chocks into the bracket.
 - ▶ Secure the wheel chocks with the safety split pins.
 - ▶ Thread the theft protection chain in the bracket.
- ✓ The wheel chocks are stowed and secured.

5.1.3 Wheel chocks with spring-clip mount

Removing the wheel chocks

- ▶ Depending on the design, push down or pull up the spring clip.
 - ▶ Remove the wheel chock.
- ✓ The wheel chocks have been removed.

Stowing the wheel chocks

- ▶ Depending on the design, push down or pull up the spring clip.
 - ▶ Insert the wheel chock in the bracket.
 - ▶ Secure the wheel chock with the spring clip.
- ✓ The wheel chocks are stowed and secured.

5.1.4 Putting on the wheel chocks




Fig. 5-1: Putting on the wheel chocks

1 Wheel chocks

- ▶ Place the wheel chocks in front of and behind a wheel of the rigid axle.
- ✓ The wheel chocks have been placed.

5.2 Landing leg winches

⚠ WARNING

Risk of accident due to tipping over!

A lack of supports when loading and unloading as well as when hitching and unhitching can result in serious injuries.

- ▶ Park the trailer on solid and level ground to avoid sinking in or tipping.
- ▶ Secure the trailer against rolling away by activating the parking brake.
- ▶ Use wheel chocks to prevent the trailer from rolling away.

⚠ WARNING

Risk of accident when driving with the landing leg winches not retracted and protruding components!

An insufficiently retracted landing leg winch can hit the ground while driving and cause serious accidents.

- ▶ Move the landing leg winches into driving position before driving off.
- ▶ Secure the crank in its holder before starting to drive.

⚠ CAUTION

Risk of injury due to crushing!

When extending the landing leg winches, limbs can be crushed between the landing leg winch and the ground.

- ▶ Avoid the danger areas.
- ▶ Wear personal protective equipment (safety shoes, gloves).

NOTE

Material damage due to longitudinal movement!

The landing leg winches can be damaged when loading and unloading as well as when the unhitched/uncoupled loaded trailer is parked for extended periods of time.

- ▶ Prevent longitudinal movement when the trailer is unhitched.
- ▶ Align the loading platform horizontally.
- ▶ When the unhitched trailer is parked for extended periods of time, lower the air suspension.

NOTE

Material damage due to overloading!

When the trailer is raised in high gear, the crank drive of the brace winches can be overloaded and damaged.

- ▶ Only use the high gear with fully unloaded and raised landing leg feet.
- ▶ Only use the load speed after the landing leg feet make ground contact.

Central axle trailers are equipped with landing leg winches.

Landing leg winches help to support the trailer when unhitching or to adjust the coupling height.

The crank drive for the landing leg winches has two speeds:

- High gear (extending/retracting the landing leg winches)
- Load speed (raising/lowering the trailer)




Fig. 5-2: Load speed and rapid speed of the landing leg winch

- 1 Hand crank
- 2 Landing leg
- A High speed
- B Load speed

INFO
 Cranking clockwise moves the landing leg downwards. Cranking counter-clockwise moves the landing leg upwards.

Also observe the enclosed supplier documentation.

Extending the landing leg winch

CAUTION
Risk of injury due to crank recoil!
 A hand crank recoil can cause injuries when releasing the hand crank.

- ▶ Slowly ease the load off the hand crank at the end of the rotation.

- ▶ Apply the parking brake (see "5.9.2 Parking brake", pg. 35).
- ▶ Ensure that the ground is load-bearing and level.
- ▶ Use wheel chocks to prevent the trailer from rolling away (see "5.1 Using wheel chocks", pg. 20).
- ▶ Lift the hand crank from the bracket.
- ▶ Engage the hand crank on the crank drive shaft until it locks into place.

- ▶ Switch on rapid speed by pulling out the hand crank (see "Fig. 5-2: Load speed and rapid speed of the landing leg winch", pg. 22).
- ▶ Wind down the landing leg winch until it touches the ground.
- ▶ Switch on load speed by pushing in the hand crank (see "Fig. 5-2: Load speed and rapid speed of the landing leg winch", pg. 22).
- ▶ Use the hand crank to wind to the desired support height. Do not fully unload the wheels while doing so.
- ▶ Use the rear braces, if available (see "5.3 Rear braces", pg. 23).
- ▶ Secure the hand crank in the bracket.
- ✓ The landing leg winch is extended and the trailer is supported.

Retracting the landing leg winch

CAUTION
Risk of injury due to crank recoil!
 A hand crank recoil can cause injuries when releasing the hand crank.

- ▶ Slowly ease the load off the hand crank at the end of the rotation.

- ▶ Check the parking brake and apply if necessary (see "5.9.2 Parking brake", pg. 35).
- ▶ Hitch the trailer (see "7.2 Hitching and unhitching the trailer", pg. 60).
- ▶ Retract the rear braces, if available (see "5.3 Rear braces", pg. 23).
- ▶ Take the hand crank from the bracket.
- ▶ Engage the hand crank on the crank drive shaft until it locks into place.
- ▶ Set to load speed by pushing in the hand crank (see "Fig. 5-2: Load speed and rapid speed of the landing leg winch", pg. 22).
- ▶ Crank up the landing leg winch until it is unloaded.

- ▶ Set to high speed by pulling out the hand crank (see "Fig. 5-2: Load speed and rapid speed of the landing leg winch", pg. 22).
- ▶ Crank up the landing leg winch to the stop.
- ▶ Secure the hand crank in the bracket.
- ✓ The landing leg winch is retracted and is in the driving position.

5.3 Rear braces

⚠ WARNING

Risk of accident when driving with rear brace folded down!

Partially folded up and/or unlocked rear braces can touch the ground while driving and cause accidents.

- ▶ Before departure, ensure that the rear braces are in the driving position and secured.

Central axle trailers are equipped with rear braces.

The rear braces prevent the trailer from overturning when loading and unloading and provide an optimal adjustment to the ramp. Depending on the version, KRONE trailers are equipped with the following rear braces:

- Rear braces with crank mechanism
- Rear braces without crank mechanism

i Also observe the enclosed supplier documentation.

5.3.1 Rear braces with crank mechanism (rigid)

⚠ WARNING

Risk of injury due to a swivelled-out hand crank!

An unsecured crank can swing out while driving and injure other persons.

- ▶ Before departure, ensure that the hand crank is in the driving position and secured.

⚠ CAUTION

Risk of injury due to crank recoil!

A hand crank recoil can cause injuries when releasing the hand crank.

- ▶ Slowly ease the load off the hand crank at the end of the rotation.

The rear braces prevent the trailer from overturning when loading and unloading and provide an optimal adjustment to the ramp.

The crank drive for the rear braces has two speeds:

- High speed (extend/retract the rear brace)
- Load speed (raise or lower the vehicle)




Fig. 5-3: Load speed and high speed of the rear brace

- 1 Hand crank
- A Load speed
- B High speed

INFO

Cranking clockwise moves the landing leg downwards. Cranking counter-clockwise moves the landing leg upwards.

i Also observe the enclosed supplier documentation.

Putting the rear braces in the support position

- ▶ Apply the parking brake (see "5.9.2 Parking brake", pg. 35).

- ▶ Ensure that the ground is load-bearing and level.
- ▶ Use wheel chocks to prevent the trailer from rolling away (see "5.1 Using wheel chocks", pg. 20).
- ▶ Raise the trailer to the desired ramp height using the air suspension (see "5.10 Air suspension", pg. 39).
- ▶ Lift the hand crank from the bracket.
- ▶ Engage the hand crank on the crank drive shaft until it locks into place.
- ▶ Switch on high speed by pulling out the hand crank (see "Fig. 5-3: Load speed and high speed of the rear brace", pg. 23).
- ▶ Wind down the landing legs until they touch the ground.
- ▶ Switch on load speed by pushing in the hand crank (see "Fig. 5-3: Load speed and high speed of the rear brace", pg. 23).
- ▶ Use the hand crank to wind to the desired support height.
 - ⇒ The rear braces are extended.
- ▶ Adjust the front landing leg winch (see "5.2 Landing leg winches", pg. 21).
- ▶ Align the trailer level in the longitudinal and transverse directions. Do not fully unload the wheels while doing so.
- ▶ Lower the trailer with the air suspension (see "5.10 Air suspension", pg. 39).
- ✓ The rear braces have been placed in the support position
- ✓ The trailer is supported at the rear only by the rear braces.

Putting the rear braces in the driving position

- ▶ Check the parking brake and apply if necessary (see "5.9.2 Parking brake", pg. 35).
- ▶ Take the hand crank from the bracket.
- ▶ Engage the hand crank on the crank drive shaft until it locks into place.

- ▶ Set to load speed by pushing in the hand crank (see "Fig. 5-3: Load speed and high speed of the rear brace", pg. 23).
- ▶ Wind up the landing leg until it is unloaded.
- ▶ Set to high speed by pulling out the hand crank (see "Fig. 5-3: Load speed and high speed of the rear brace", pg. 23).
- ▶ Wind up the landing leg up to the stop.
- ▶ Secure the hand crank in the bracket.
- ✓ The rear braces have been put in driving position and the crank is secured.

5.3.2 Rear braces without crank mechanism

Putting the rear braces in the support position




Fig. 5-4: Folding down the rear brace

- 1 Bolt for the height lock
 - 2 Spring cotter pin for the folding mechanism
 - 3 Retainer handle
 - 4 Bolt for the folding mechanism
- ▶ Raise the trailer to the desired ramp height using the air suspension (see "5.10 Air suspension", pg. 39).
 - ▶ Remove the spring cotter pin for the folding mechanism.
 - ▶ Support the rear brace by its handle and remove the bolt for the folding mechanism.
 - ▶ Fold down the rear brace.

- ▶ Reinsert the bolt for the folding mechanism.




Fig. 5-5: Adjusting the height of the rear brace

- 1 Bolt for the height lock
- 2 Spring cotter pin for the height lock

- ▶ Secure the bolt for the folding mechanism with the spring cotter pin.
- ▶ Remove the spring cotter pin for the height lock.
- ▶ Hold the foot of the rear brace and remove the bolt for the height lock.
- ▶ Pull out the foot of the rear brace as necessary to the length required by the loading height.
- ▶ Reinsert the bolt for the height lock and secure the foot of the rear brace in the desired position.
- ▶ Secure the bolt for the height lock with the spring cotter pin.
- ▶ Fold down the second rear brace in the same way.
- ▶ Adjust the front landing leg winch (see "5.2 Landing leg winches", pg. 21).
- ▶ Align the trailer level in the longitudinal and transverse directions. Do not fully unload the wheels while doing so.
- ▶ Lower the trailer with the air suspension (see "5.10 Air suspension", pg. 39).
- ✓ The rear braces have been placed in the support position.
- ✓ The trailer is supported at the rear only by the rear braces.

Putting the rear braces in the driving position

- ▶ Lift the trailer with the air suspension until the rear braces no longer touch the ground (see "5.10 Air suspension", pg. 39).
- ▶ Remove the spring cotter pin for the height lock.
- ▶ Hold the foot of the rear brace and remove the bolt for the height lock.
- ▶ Push the foot for the rear brace upwards.
- ▶ Reinsert the bolt for the height lock and secure the foot of the rear brace in the top position.
- ▶ Secure the bolt for the height lock with the spring cotter pin for the height lock.
- ▶ Remove the spring cotter pin for the folding mechanism.
- ▶ Hold the rear brace by its handle and remove the bolt for the folding mechanism.
- ▶ Fold up the rear brace.
- ▶ Reinsert the bolt for the folding mechanism.
- ▶ Secure the bolt for the folding mechanism with the spring cotter pin.
- ▶ Fold up the second rear brace in the same way.
- ✓ The rear braces have been placed in the driving position and secured.

5.4 Draw fork

Turnframe trailers are equipped with draw forks. To properly hitch the trailer, the coupling ring of the draw fork must be set to the corresponding height of the tractor unit's trailer coupling. The trailer's draw fork is equipped with height-adjustment devices for that purpose (see "Fig. 5-6: Draw fork with height adjustment device", pg. 26).

Depending on the version, the draw fork on the trailer is rigid or has an adjustable length. A tool is used to adjust the length.

The draw fork can also be optionally equipped with rapid resetting that requires no tools.

Adjusting the height of the draw fork

Depending on the equipment, two versions of the height-adjustment device are possible.

NOTE

A draw fork set to the wrong height can cause material damage!

A draw fork set to the wrong height can cause damage to the trailer or tractor unit during hitching.

- ▶ Before hitching and unhitching, set the draw fork to the corresponding height of the tractor unit's trailer coupling.




Fig. 5-6: Draw fork with height adjustment device

- 1 Draw fork
- 2 Height adjustment device

Version 1




Fig. 5-7: Tension spring with turnbuckle

- 1 Turnbuckle
- 2 Turnbuckle lever
- 3 Draw spring

- ▶ Use the turnbuckle lever to turn the turnbuckle until the coupling ring has reached the required height.
- ✓ The height of the draw fork is set.

Version 2




Fig. 5-8: Tension spring with turnbuckle, version 2

- 1 Lock nut
- 2 Turnbuckle
- 3 Draw fork

- ▶ Loosen the lock nut.
- ▶ Use the turnbuckle lever to turn the turnbuckle until the coupling ring has reached the required height.

- ▶ Tighten the lock nut.
- ✓ The height of the draw fork is set.

Adjusting the length of the draw fork using a tool

⚠ WARNING

accident hazard due to an unsecured length adjustment at the draw fork!

An unsecured length adjustment at the draw fork can cause accidents.

- ▶ Ensure that the threaded bolt is properly secured after adjusting the length or changing the tractor unit.

Length adjustment, or a change of tractor unit, can cause the overall length of the train to be exceeded. Check the following points every time you adjust the length or during every vehicle change:

- Ensure that the threaded bolts are properly secured with the securing devices,
- Check the legally permitted overall length of the train and
- the distance between trailer and tractor unit.




Fig. 5-9: Length adjustment with tool

- 1 Threaded bolt (head)
- 2 Nut with threaded bolt
- 3 Retainer plate

- ▶ Unhitch the trailer (see "7.2 Hitching and unhitching the trailer", pg. 60).

- ▶ Loosen the nuts with a spanner and unscrew them from the threaded bolts.
- ▶ Remove the threaded bolts.
- ▶ Place the draw bar in the desired position by shifting it in or out.
- ▶ Reinsert the threaded bolts.
- ▶ Screw the nuts on the thread and tighten at approx. 300 Nm. The draw-bar tube should not have any play in the clamp bearing.
- ▶ Secure the nuts using the retainer plates.
- ✓ The length of the draw fork is set.

Adjusting the length of the draw fork using rapid resetting




Fig. 5-10: Length adjustment via rapid resetting

- 1 Clamping bracket
- 2 Control lever
- 3 Crown nut

- ▶ Unhitch the trailer (see "7.2 Hitching and unhitching the trailer", pg. 60).
- ▶ Pull the control lever from the clamping bracket.
- ▶ Insert the control lever into the crown nut's groove and release it by turning counterclockwise.
- ▶ Use the control lever to unscrew the crown nuts from the threaded bolt together.
- ▶ Remove the threaded bolts.

- ▶ Place the draw bar in the desired position by shifting it in or out.
 - ▶ Reinsert the threaded bolts. The threaded bolts are only secured against twisting with the flattened side facing upwards.
 - ▶ Turn the crown nut onto the threaded bolts.
 - ▶ Insert the control lever into the crown nut's groove and tighten it by turning clockwise.
 - ▶ Insert the control lever into the clamping bracket.
- ✓ The length of the draw fork is set.

5.5 Drawbar wale

Central axle trailers are equipped with a drawbar wale.

Adjusting the height of the drawbar wale

NOTE

An improperly set drawbar wale can cause material damage!

A drawbar wale set to the wrong height can cause damage to the trailer or tractor unit during hitching.

- ▶ Before hitching and unhitching, set the drawbar wale to the corresponding height of the tractor unit's trailer coupling using the landing leg winch.

The height on the drawbar wale is set using the landing leg winch (see "5.2 Landing leg winches", pg. 21).

Adjusting the length of the drawbar wale

⚠ WARNING

Risk of accident due to an unsecured length adjustment at the drawbar wale!

An unsecured length adjustment of the drawbar wale can cause accidents.

- ▶ Ensure that the plug-in bolts are properly secured with the securing devices after adjusting the length or changing the tractor unit.

Length adjustment, or a change of tractor unit, can cause the overall length of the train to be exceeded. Check the following points every time you adjust the length or during every vehicle change:

- Ensure that the plug-in bolts are properly secured with the securing devices,
- Check the legally permitted overall length of the train and
- the distance between trailer and tractor unit.




Fig. 5-11: Plug-in bolts on drawbar wale

- 1 Safety split pin
- 2 Flat washer
- 3 Plug-in bolt

- ▶ Unhitch the trailer (see "7.2 Hitching and unhitching the trailer", pg. 60).
- ▶ Remove the safety split pin from the plug-in bolts.
- ▶ Remove the flat washers.




Fig. 5-12: Hand lever on the drawbar wale

- 1 Hand lever secured with spring snaps
- 2 Hand lever swivelled upwards

- ▶ Unhook the spring snap from the securing eyelets of the hand lever.
- ▶ Swivel the hand lever upwards.
- ▶ Pull out the plug-in bolts.
- ▶ Place the drawbar wale in the desired position by shifting it in or out.
- ▶ Slide in the plug-in bolts.
- ▶ Swivel the hand lever downwards.
- ▶ Hook the spring snap into the securing eyelets of the hand lever.
- ▶ Place the flat washer on the plug-in bolt.
- ▶ Secure the plug-in bolts with safety split pins.
- ✓ The length of the drawbar wale is set.
- ✓ The plug-in bolts are properly secured.

5.6 Supply and control connections

⚠ DANGER

Disconnected supply and control connections pose a risk of accident!

Driving without the supply and control connections being connected between the tractor unit and the trailer affects the driving and brake behaviour and is prohibited by law. There is a risk of accidents due to the malfunction.

Before each trip:

- ▶ Connect the compressed air supply.
- ▶ Connect the electrical power supplies for the vehicle lighting.
- ▶ Connect the electrical power supplies for the brake system.

⚠ WARNING

Damaged or inadequate supply and control connections pose a risk of accident!

Damaged or inadequate supply and control connections between the tractor unit and trailer affect driving and braking behaviour and can lead to accidents.

- ▶ Ensure that all compressed air connections are properly connected and not leaking.
- ▶ Ensure proper functioning of the couplings.
- ▶ Replace damaged rubber seals or damaged coupling heads on the tractor unit and trailer.
- ▶ Ensure that the EBS plug is properly locked.

⚠ WARNING

Improperly connecting and disconnecting the supply and control connections poses a risk of accident!

Improperly connected compressed air and electrical lines affect driving and braking behaviour and can lead to accidents.

- ▶ Observe the connection sequence of the lines when hitching and unhitching.
- ▶ Always close the coupling heads with the protective caps after unhitching the brake lines.

For axle and brake control as well as air and power supply, the trailer is equipped with various connections on its front side.

The supply and control connections on the coupling support of central axle trailers are designed as a socket.

On turnframe trailers, the supply and control connections are fastened to the draw fork as a strand with plugs.




Fig. 5-13: Supply and control connections on the central axle trailer

- 1 Vehicle lighting socket N ISO 1185, 7-pin (black)
- 2 Vehicle lighting socket S ISO 3731, 7-pin (white)
- 3 Supply compressed air coupling (red)

- 4 Brake compressed air coupling (yellow)
- 5 Vehicle lighting socket ISO 12098, 15-pin
- 6 Brake EBS socket power supply ISO 7638

More information about the plug and socket assignment can be found in the technical data (see "13.2 Plugs and socket pin assignments", pg. 89).

Coupling

Depending on the design, the following couplings may be installed:

- Standard coupling heads (standard),
- Duo-Matic coupling and
- C-coupling heads.

Connecting the standard coupling




Fig. 5-14: Example of standard coupling head

- ☑ The parking brake on the tractor unit is applied.
- ☑ The parking brake on the trailer is applied (see "5.9.2 Parking brake", pg. 35).
- ▶ Check the cleanliness and integrity of the sealing surfaces on the coupling heads. Clean if necessary.
- ▶ Always connect the brake compressed air coupling (yellow) first.
- ▶ Connect the supply compressed air coupling (red).

- ▶ Connect the power supply (vehicle lighting) and the brake power supply (EBS).
- ✓ The supply and control connections are now connected.

Disconnecting the standard coupling

- ☑ The parking brake on the tractor unit is applied.
- ☑ The parking brake on the trailer is applied (see "5.9.2 Parking brake", pg. 35).
- ▶ Always disconnect the supply compressed air coupling (red) first.
- ▶ Disconnect the brake compressed air coupling (yellow).
- ▶ Disconnect the power supply (vehicle lighting) and the brake power supply (EBS).
- ▶ Close the disconnected coupling heads and plugs with the protective caps.
- ✓ The supply and control connections are disconnected.

Connecting the Duo-Matic coupling




Fig. 5-15: Duo-Matic coupling

- 1 Compressed air coupling (tractor unit part)
- 2 Compressed air coupling (trailer part)

- ☑ The parking brake on the tractor unit is applied.
- ☑ The parking brake on the trailer is applied (see "5.9.2 Parking brake", pg. 35).

- ▶ Check the cleanliness and integrity of the sealing surfaces on the coupling heads. Clean if necessary.
- ▶ Pull down the compressed air coupling (trailer part) lever and insert the coupling head (tractor unit part).
- ▶ Connect the power supply (vehicle lighting) and the brake power supply (EBS).
- ✓ The supply and control connections are now connected.

Disconnecting the Duo-Matic coupling

- ☑ The parking brake on the tractor unit is applied.
- ☑ The parking brake on the trailer is applied (see "5.9.2 Parking brake", pg. 35).
- ▶ Pull down the coupling head (trailer part) lever and remove the coupling head (tractor unit part).
- ▶ Disconnect the power supply (vehicle lighting) and the brake power supply (EBS).
- ✓ The supply and control connections are disconnected.

Connecting C-coupling heads




Fig. 5-16: C-coupling heads (trailer)

- 1 Supply compressed air coupling
- 2 Brake compressed air coupling

- ☑ The parking brake on the tractor unit is applied.
- ☑ The parking brake on the trailer is applied (see "5.9.2 Parking brake", pg. 35).

- ▶ Check the cleanliness and integrity of the sealing surfaces on the coupling heads. Clean if necessary.
- ▶ Always connect the brake compressed air coupling first.
- ▶ Connect the supply compressed air coupling.
- ▶ Connect the power supply (vehicle lighting) and the brake power supply (EBS).
- ✓ The supply and control connections are now connected.

Disconnecting C-coupling heads

- ☑ The parking brake on the tractor unit is applied.
- ☑ The parking brake on the trailer is applied (see "5.9.2 Parking brake", pg. 35).
- ▶ Always disconnect the supply compressed air coupling first.
- ▶ Disconnect the brake compressed air coupling.
- ▶ Disconnect the power supply (vehicle lighting) and the brake power supply (EBS).
- ✓ The supply and control connections are disconnected.

5.7 Blind couplings

NOTE

Sagging supply and control connections can cause material damage!

Sagging supply and control connections can become contaminated on unhitched trailers, thereby causing material damage.

- ▶ On unhitched trailers, always plug the lines and plugs of all supply and control connections into their designated blind couplings.




Fig. 5-17: Possible arrangement of the supply and control connections on a blind coupling

- 1 EBS plug
- 2 Plug (white), 7-pin
- 3 Plug, 15-pin
- 4 Brake coupling
- 5 Plug (black), 7-pin
- 6 Compressed air supply coupling

- ▶ Close the coupling heads.
- ▶ Place the supply and control connections on the brackets.
- ▶ Insert the cable plugs into their designated blind plugs.
- ✓ The supply and control connections are secured.

5.8 Draining the compressed air tanks

⚠ WARNING

Risk of accident due to condensation water!

Condensation water in the compressed air tank can cause corrosion and affect the functionality of the brake system and the air suspension. Frozen condensation water can lead to total failure of the brake system and to serious accidents.

- ▶ Check the compressed air tank for the presence of condensation water.
- ▶ Drain any existing condensation water.
- ▶ Drain existing condensation water more frequently in case of low or strongly fluctuating outside temperatures.

The tractor vehicles are fitted with air dryers. This means that condensate in the compressed air is largely prevented. During cold periods of the year, or when air humidity is high, condensation water can still form and collect in the compressed air tank. The compressed air supply for the brake system and the air suspension is stored in the compressed air tanks. Existing condensation water can be drained using the water drain valve.




Fig. 5-18: Compressed air tank

- 1 Compressed air tank
- 2 Water drain valve

- ▶ Push the valve pins of the water drain valves on all compressed air tanks to the side until the condensation water is fully drained.
- ✓ The condensation water is drained.

5.9 Brake system

⚠ DANGER

Risk of accidents due to non-functional EBS!

If the EBS plug connection function is not established, the EBS of the vehicle and the automatic load-dependent brake power regulation cannot work. The vehicle is overbraked and the wheels may lock. Serious traffic accidents could occur. Driving without the EBS plug connection is prohibited by law.

- ▶ Only drive with an approved, connected and functioning EBS plug connection.
- ▶ Always connect the EBS plug connections between the tractor unit and the trailer.
- ▶ Verify the EBS plug connection via a system check (the magnetic valves in the EBS modulator are audibly and briefly activated and deactivated for 2 seconds after "ignition on")
- ▶ Only use plug connections that comply with the regulations.
- ▶ Have the fault immediately repaired by the nearest contract workshop.

⚠ WARNING

Risk of accident due to unharmonised brake power tuning!

Unharmonised brake power between the tractor unit and trailer may lead to insufficient or excessive trailer braking values. This can cause wear and accidents.

- ▶ Monitor the automatic coupling force control to harmonize the brake power.
- ▶ Pay attention to the sticker on the trailer.

▲ WARNING

Risk of accident due to insufficient air supply pressure!

If the air supply pressure is < 4.5 bar, the trailer can no longer be stopped using the service brake. If the pressure is < 2.5 bar on the red coupling head, the trailer will automatically be stopped via the spring storage.

- ▶ As soon as the warning display/warning lamp lights up (red and yellow), stop the trailer and park at a suitable location.
- ▶ Check the pressure supply and call a repair service if necessary.

▲ WARNING

Risk of accident due to pressure loss inside the brake system!

Pressure loss in the brake system due to a leak causes a deterioration in the service brake's effectiveness until the parking brake is automatically activated. Unintended vehicle movement can cause an accident.

- ▶ For extended stops, additionally secure the trailer from rolling away by using the parking brake and wheel chocks.
- ▶ Have an authorized specialist workshop eliminate the leaks.

INFO

The brake system equipment on the trailer is state of the art. The equipment level of the brake equipment on the tractor unit depends on the manufacturer and type. Likewise, the coupling force controllers of the tractor units in relation to the trailer braking and the control system limits also differ. It is therefore sensible to observe the braking behaviour of the tractor combination and to adjust it if necessary.

INFO

The trailer may only be towed by tractor units that ensure the effectiveness of the EBS system. The EBS system includes the ABS function (automatic anti-lock system ABS), the ALB function (automatic load-dependent braking), and the RSS function (vehicle stabilization for air-suspended vehicles). Full EBS functionality is only ensured when used in conjunction with tractor units equipped with EBS equipment (ISO 7638 socket, 7-pin).

 Also observe the enclosed supplier documentation.

KRONE trailers are equipped with a brake system according to the current version of UN-ECE Regulation 13.

A system check of the electronic brake system (EBS) is performed upon turning on the ignition in the tractor unit and during the trip. Errors in the EBS brake system are displayed via a warning lamp/warning display on the tractor unit's dashboard. The warning lamp/warning display lights up after turning on the ignition. If no error is detected, the warning lamp/warning display turns off after approx. two seconds.

If an error was detected during the last trip (e.g. sensor error), the warning lamp/warning display lights up and turns off if the speed is > 7 km/h.

- ▶ If the warning lamp/warning display does not turn off at the start of the trip either, have the fault repaired by a specialist workshop.

The brake system has two independent brake circuits:

- Service brake
- Parking brake

5.9.1 Service brake

INFO

Repeated operation of the service brake when the supply lines are uncoupled uses up compressed air from the air reservoir. The trailer is then only partially braked (depending on the air supply).

When the supply conduit is unhitched, the trailer is automatically braked. The black control knob on the control unit can be used to release the service brake to manoeuvre the trailer without a connected compressed air supply (see "7.3 Manoeuvring the trailer without a connected compressed air supply", pg. 63).




Fig. 5-19: Service brake for the central axle trailer

- 1 Black control knob (manoeuvring)




Fig. 5-20: Service brake for the turnframe trailer

- 1 Black control knob (manoeuvring)

Disengaging the service brake

- ▶ Press the black control knob.
- ✓ The service brake is disengaged.
- ✓ If the parking brake is also released, the trailer is not braked.

Applying the service brake

- ▶ Pull out the black control knob.
- ✓ The service brake is applied.
- ✓ The trailer is partially braked (depending on the air supply).

Connecting the supply conduit will automatically push out the black control knob to the driving position again.

5.9.2 Parking brake

NOTE

Property damage by driving with the parking brake applied!

Driving with the parking brake applied will damage the trailer's brakes and axles after a short time.

- ▶ Disengage the parking brake before starting the trip.

The parking brake is its own brake circuit. It is applied via the brake cylinder's spring storage parts.

The parking brake must be actuated manually. Before unhitching and for parking, the trailer must be braked using the red control knob.

To tow or manoeuvre without compressed air, the parking brake can be disengaged with the emergency release system (see "5.9.3 Emergency release devices for the parking brake", pg. 36).




Fig. 5-21: Parking brake for central axle trailer

- 1 Red control knob (park)




Fig. 5-22: Parking brake for turnframe trailer

- 1 Red control knob (park)

Applying the parking brake

- ▶ Pull out the red control knob.
- ✓ The parking brake is applied
- ✓ The trailer is braked and can be parked.

Disengaging the parking brake

⚠ WARNING

Possible risk of accidents when releasing the parking brake with the service brake released at the same time!

The trailer is not braked if the parking brake and the service brake are released at the same time. The trailer is not braked, it can roll away and cause an accident.

- ▶ Only release the service and parking brake at the same time when a towing or manoeuvring vehicle is connected to the trailer.
- ▶ Additionally secure the trailer with wheel chocks when parking or standing on slopes.

INFO

The parking brake does not disengage automatically. Prior to starting off it must be disengaged manually.

- ☑ The trailer is hitched.
- ☑ The supply and control lines are connected.
- ▶ Press the red control knob.
- ✓ The parking brake is released and the trailer is not braked.

5.9.3 Emergency release devices for the parking brake

⚠ WARNING

Risk of accident due to rolling away!

When the emergency release device is activated, the parking brake does not function. When it is not braked, the trailer can roll away and cause serious injuries and material damage.

- ▶ Only release the service and parking brake when a towing or manoeuvring vehicle is connected to the trailer.
- ▶ Use wheel chocks to prevent the trailer from rolling away.
- ▶ Insert the emergency release screw in its holder before starting to drive.

⚠ WARNING

Risk of accidents when driving with the emergency release screw!

Driving with the emergency release screw fitted can make the brake system inoperative and result in accidents.

- ▶ Ensure that the emergency release screw has been returned to the parking position before driving off again.

If the compressed air for the parking brake's spring storage fails due to a defect, the braking effect can be cancelled via an emergency release device on the brake cylinders.

The spring storage of the brake system can be operated without compressed air using the emergency release device. When the emergency release device is activated, the spring storage is clamped on each wheel and the parking brake is opened. By doing so, the trailer can be towed or manoeuvred.

INFO

The shape of the spring storage can vary according to the model and differ from the figure shown.

Activating the emergency release device for the parking brake




Fig. 5-23: Spring storage with emergency release device

- 1 Emergency release screw
- 2 Retainer nut
- 3 Flat washer
- 4 Bracket
- 5 Protective cap

- ▶ Use wheel chocks to prevent the trailer from rolling away (see "5.1 Using wheel chocks", pg. 20).
- ▶ Loosen the retainer nut and flat washer.
- ▶ Remove the emergency release screw from the holder.
- ▶ Open the cap.




Fig. 5-24: Activating the emergency release screw

- 1 Emergency release screw
- 2 Flat washer
- 3 Retainer nut

- ▶ Insert the emergency release screw.
- ▶ Turn the emergency release screw clockwise (90°) until it engages.
- ▶ Screw the retainer nut and flat washer onto the emergency release screw.
- ▶ Tighten the retainer nut with the suitable spanner until the stop.
- ✓ The spring storage is mechanically tensioned and the brake cylinder has no more braking effect.
- ▶ Activate the emergency release device on all the spring storage devices.
- ✓ The emergency release device is activated and the service and parking brakes are without function.
- ✓ The trailer is not braked.

Deactivating the emergency release device for the parking brake




Fig. 5-25: Deactivating the emergency release screw

- 1 Emergency release screw
- 2 Flat washer
- 3 Retainer nut

- ▶ Unscrew the retainer nut and flat washer from the emergency release screw using a suitable spanner.
- ▶ Turn the emergency release screw key counter-clockwise (90°) and disengage it.
- ▶ Remove the emergency release screw.
- ▶ Insert the emergency release screw in its holder.
- ▶ Screw the retainer nut and flat washer onto the emergency release screw and tighten up to the stop with a suitable spanner.
- ▶ Close the cap.
- ✓ The spring storage is mechanically released and the brake is functional.
- ▶ Deactivate the emergency release device on all the spring storage devices.
- ✓ The emergency release device is deactivated and the service and parking brakes are functional.

5.10 Air suspension

⚠ WARNING

Risk of accident due to fully lowered or raised vehicle!

Failure to set the air suspension to the "Drive" position before starting off can result in a risk of accidents due to impaired driving characteristics or vehicle collisions in passageways.

- ▶ Always move the air suspension into driving position before driving off. The only exception is manoeuvring at walking speed.

⚠ CAUTION

Risk of injury due to crushing!

When lowering the trailer, the clearance under the trailer is reduced. Persons between the road and vehicle parts can be crushed and seriously injured.

- ▶ Avoid the danger areas.
- ▶ When operating the air suspension, avoid having persons underneath the trailer.

NOTE

Material damage due to grounding!

On vehicles with a large lifting height, the distance between the ground and suspension elements is reduced when reaching maximum lifting height. The spring elements on the axle could ground when manoeuvring and be damaged.

- ▶ For vehicles with large lifting heights, always put the air suspension in driving position.

KRONE trailers are equipped with an air suspension system. The vehicle height (e.g. to adjust it for a ramp) can be adjusted in two ways:

- Manually
- Electronically controlled

 Also observe the enclosed supplier documentation.

Depending on the make and design of the lifting and lowering valves, the following functions can be carried out using the air suspension's control lever:

Control lever position	Function
Drive*	The trailer is always kept at the same height, regardless of the load.
Raised	The trailer is raised, e.g. to adjust it for a ramp.
Raised and engaged	The trailer is raised to the maximum possible lifting height.
Lowered	The trailer is lowered, e.g. to adjust it for a ramp.
Lowered and engaged	The trailer is lowered down to its mechanical limit (air suspension bellows without overpressure)
Stop	The trailer height achieved via lifting or lowering is maintained.

* The driving position cannot be set manually on electronically controlled air suspension. Instead, the ride height is automatically set at a driving speed of > 15 km/h.

The operating instructions for the air suspension's control lever are shown as a pictogram on the control unit.




Fig. 5-26: Example pictogram of mechanically controlled air suspension




Fig. 5-27: Example pictogram of electronically controlled air suspension

To prevent chassis damage, the version with the lifting-lowering valve with automatic ride height resetting automatically sets the trailer back to the driving position when the vehicle speed exceeds 15 km/h.

NOTE

Driving with the wrong lifting height causes material damage!

Driving at the minimum or maximum lifting height on an electronically controlled air suspension can cause material damage to the trailer.

- ▶ Do not drive at the minimum or maximum lifting height.

⚠ CAUTION

Risk of accidents due to tipping movements!

If there is an improper power interruption, this may, among other things, result in the valve switching states being unclear on electronically controlled air suspension systems. Unclear valve switching positions can result in tipping movements in the longitudinal direction of the loading surface on lift axle controls. These are especially dangerous when using a forklift to load or unload from the rear.

- ▶ Properly shut down the entire electronic system before hitching and unhitching the trailer.
- ▶ Before disconnecting the supply lines (compressed air, vehicle electronics and ISO-7638 EBS power supply), switch the ignition in the tractor to "off" (terminal 15 = de-energised).

Optionally, KRONE trailers can also be fitted with a system for electronically controlled air suspension, e.g. via Wabco's ECAS system. It electronically controls the vehicle's ride height if there is a power supply and an adequate compressed air supply.

KRONE trailers with electronically controlled air suspension can be optionally equipped with various electronic control devices (control box, SmartBoard, electronic buttons, etc.).




Fig. 5-28: Example of a control box (Wabco)

If there is sufficient air and power supply, the system can automatically regulate the ramp height. If there is no power supply, the ramp can also be adjusted via the electronically controlled air suspension with the control lever on the control unit.

 Also observe the enclosed supplier documentation.

5.11 Lift axles

WARNING

Risk of accidents due to the raising and lowering of the lift axle!

The lift axles are automatically raised depending on the load state. If the tractor unit's ignition is turned off, the raised lift axles are lowered. There is an increased risk of injury in the danger area of the wheels.

- ▶ Instruct persons to leave the hazard area of the wheels during loading and unloading.

The central axle version of KRONE trailers can be equipped with an electronic lift axle control with fully automatic operation.

Fully automatic lifting of lift axles depending on the vehicle's axle weight (air bellows pressure) only takes place if the EBS plug connection (ISO 7638) is active and the vehicle speed is greater than 15 km/h for the first time. When the ignition is interrupted while the vehicle is at standstill, the lift axle is lowered independent of the vehicle's axle weight.

Manually overriding the fully-automatic electronic lift axle control

Automatic control is cancelled if the lift axle control is manually operated on the control switch. The dependencies on the vehicle axle weight and the vehicle speed are not taken into account in this event. An EBS plug connection is a precondition for this. The control switch for manual lift axle control is on the control unit. Controlling a further lift axle is done on the same control switch on the fully-automatic and electronic

lift axle control systems. The design and arrangement of the control switch depends on the vehicle equipment.

Using the lift axle's control switch, the driver can interrupt the automation of the lift axle control to activate the following functions:

- **Starting aid:** Manually raise the lift axle
A lift axle can be raised by force at a maximum vehicle speed of 30 km/h and up to 30% overload for the axle remaining on the ground.
- **Manoeuvring aid:** Manually raise the lift axle
A lift axle can be raised by force at a maximum vehicle speed of 30 km/h and up to 0 % overload for the axle remaining on the ground.
- **Deactivating the lift axle automatic system:** Manually lower the lift axles

The starting aid function refers to a lift axle in the first position of the rear axle group on 3-axle trailers. The automatic lift axle control is re-activated by turning the ignition off and on in the tractor unit.




Fig. 5-29: Control unit

- 1 Lift axle control switch

- ▶ Operate the control switch time-dependently (rotary push-button switch with reset).
- ✓ The lift axle is raised in compliance with legal regulations when the button is actuated for less than 5 seconds (starting aid).
- ✓ When operated for longer than 5 seconds, the lift axle automatic system is deactivated and the lift axle remains down regardless of the load state (force lowered). This position is kept as long as the ignition of the tractor is not interrupted.




Fig. 5-30: Control switch functions of the lift axle control system

5.12 Rigid axle

KRONE trailers are equipped with rigid axles.

Also observe the enclosed supplier documentation.

5.13 Step-on devices

CAUTION

Risk of injury from falls!

Using unsuitable items to climb onto or off the vehicle or jumping from the load compartment can result in falls with injuries.

- ▶ Only use the built-in step-on devices.
- ▶ Do not jump down from the load compartment.

KRONE trailers can be equipped with the following climbing aids:

- Hand strap (see "5.13.1 Hand strap", pg. 42)
- Aluminium ladder (see "5.13.2 Aluminium ladder", pg. 42)
- Fold-down steps (at rear wall, folding) (see "5.13.3 Fold-down steps", pg. 43)

5.13.1 Hand strap

For safe mounting and dismounting, a hand strap is installed on the inside of the corner post.

- ▶ Use hand straps for safe mounting and dismounting.
- ▶ For mounting and dismounting, always face the ladder so that the hand straps can be used without problems.

5.13.2 Aluminium ladder

WARNING

Risk of accident caused by an unsecured ladder!

An unsecured ladder can drop onto the road while driving and cause an accident.

- ▶ Prior to departure, check that the ladder is properly secured.

To facilitate climbing into the trailer, an aluminium ladder is located under the chassis.




Fig. 5-31: Aluminium ladder

- 1 Aluminium ladder
- 2 Bracket
- 3 Lynch pin

Using the aluminium ladder

- ▶ Remove the lynch pin.
- ▶ Pull out the ladder.
- ▶ Position the ladder.
- ✓ The ladder can be used to climb onto or off the vehicle.

Slide in and secure the aluminium ladder

- ▶ Slide in the ladder over the brackets.
- ▶ Secure the ladder with the lynch pins.
- ✓ The ladder is inserted and secured.

5.13.3 Fold-down steps

KRONE trailers with a folding rear wall and folding side walls can be equipped with fold-down steps.




Fig. 5-32: Fold-down steps on the folding rear wall

- 1 Fold-down steps

- ▶ Fold out the fold-down steps before use.
- ▶ Use hand straps for mounting and dismounting (see "5.13.1 Hand strap", pg. 42).
- ▶ Fold in the fold-down steps again after use.

5.14 Side collision protection

⚠ WARNING

Risk of accident when driving with the side collision protection folded up!

Driving with the side collision protection folded up is not permitted by law. In a collision, other motorists can get below the trailer and be fatally injured.

- ▶ Only drive with the side collision protection folded down and locked in place on both sides.

NOTE

Material damage when loading the trailer!

A folded-down side collision protection can cause material damage to the trailer when loading the trailer (e.g. during rail transport).

- ▶ Fold up and lock the side collision protection on both sides when loading the trailer.

KRONE trailers have a side collision protection. In addition to the fixed version, the folding version provides the possibility of folding up the side collision protection for maintenance work, to remove tools, to change the spare wheel or similar.

5.14.1 Folding side collision protection with lock

⚠ CAUTION

Risk of injury from the side collision protection folding down unintentionally!

An unlocked side collision protection can suddenly fold down and injure people or swing outwards while driving, thereby causing accidents.

- ▶ Lock the side collision protection in every position.




Fig. 5-33: Folded-down side collision protection ((rear view))

- 1 Drilled hole for the plug-in bolt while folded up
- 2 Plug-in bolts with spring pin

Folding up the side collision protection

- ▶ Pull out the spring pin on both plug-in bolts.
 - ▶ Pull out the plug-in bolts.
 - ▶ Fold up the side collision protection.
 - ▶ Insert the plug-in bolts into the drilled holes.
 - ▶ Secure the plug-in bolts with the spring pins.
- ✓ The side collision protection is folded up and secured.

Folding down the side collision protection

- ▶ Pull out the spring pin on both plug-in bolts.
 - ▶ Pull out the plug-in bolts.
 - ▶ Fold down the side collision protection.
 - ▶ Insert the plug-in bolts into the drilled holes.
 - ▶ Secure the plug-in bolts with the spring pins.
- ✓ The side collision protection is folded down and secured.

5.15 Spare wheel bracket

⚠ WARNING

Risk of accident from an unsecured spare wheel!

An unsecured spare wheel can fall off when driving and cause serious accidents.

- ▶ Properly secure the spare wheel.
- ▶ Only transport wheels that are designed for the spare wheel bracket.
- ▶ Check the spare wheel bracket for damage.
- ▶ Immediately repair the spare wheel bracket if defective.

⚠ CAUTION

Risk of injury due to a falling spare wheel!

The weight of a falling spare wheel can cause injuries.

- ▶ Work carefully when changing a spare wheel.

KRONE trailers can be equipped with a spare wheel bracket. Depending on the equipment, the following versions are possible:

- Spare wheel with basket storage (see "5.15.1 Spare wheel with basket storage", pg. 45)
- Spare wheel with winch (see "5.15.2 Spare wheel with winch", pg. 45)
- Spare wheel in the pallet storage box (see "5.15.3 Spare wheel in the pallet storage box", pg. 46)

5.15.1 Spare wheel with basket storage




Fig. 5-34: Spare wheel with basket storage version 1

- 1 Storage basket
- 2 Rim holder
- 3 Securing device

Spare wheel removal

- ▶ Fold up the side collision protection, if necessary (see "5.14 Side collision protection", pg. 43).
- ▶ Remove the securing device.
- ▶ Unscrew the rim holder.
- ▶ Remove the spare wheel from the storage basket.
- ✓ The spare wheel has been removed.

Spare wheel insertion

- ▶ Insert the spare wheel in the storage basket.
- ▶ Firmly screw the rim holder.
- ▶ Install the securing device.
- ▶ Fold down the side collision protection, if necessary (see "5.14 Side collision protection", pg. 43).
- ▶ The spare wheel is inserted.

5.15.2 Spare wheel with winch

⚠ CAUTION

Risk of injury due to a falling spare wheel!

The weight of a falling spare wheel can cause injuries.

- ▶ Work carefully when changing a spare wheel.
- ▶ Before removing the securing devices, check the support cable and winch for function and damage.




Fig. 5-35: Spare wheel with winch

- 1 Retainer rod
- 2 Hand crank
- 3 Tubular nut
- 4 Spring cotter pin

Spare wheel removal

- ▶ Fold up the side collision protection, if necessary (see "5.14 Side collision protection", pg. 43).
- ▶ Remove the spring cotter pin.
- ▶ Remove the retainer rod from the tubular nuts.
- ▶ Unscrew the tubular nuts counter-clockwise using the retainer rod.
- ▶ Turn the hand crank counter-clockwise and slowly lower the spare wheel to the ground using the winch.

- ▶ Let out the support cable until the spare wheel can be removed from the spare wheel bracket.
- ✓ The spare wheel has been removed.

Spare wheel insertion

- ▶ Place the spare wheel under the support cable.
- ▶ Let out the support cable until the spare wheel bracket can be fastened to the rim.
- ▶ Turn the crank counter-clockwise and slowly lift the spare wheel using the winch until the support cable is slightly tensioned.
- ▶ Screw in the tubular nuts clockwise using the retainer rod.
- ▶ Insert the retainer rod into the tubular nuts.
- ▶ Secure the retainer rod with the spring cotter pin.
- ▶ Fold down the side collision protection, if necessary (see "5.14 Side collision protection", pg. 43).
- ✓ The spare wheel is inserted.

5.15.3 Spare wheel in the pallet storage box

Turnframe trailers can be equipped with a spare wheel in the pallet storage box. In this version, the spare wheel is fastened to a pull-out bracket in the pallet storage box.

Spare wheel removal

- ▶ Open the pallet storage box (see "5.17 Pallet storage box", pg. 48).
- ▶ Lift the pull-out bracket out of the locks.
- ▶ Remove the spare wheel.
- ✓ The spare wheel has been removed.

Spare wheel insertion

- ▶ Place the spare wheel on the pull-out bracket.

- ▶ Lift the pull-out bracket with the spare wheel into the lock and slide it into the pallet storage box.
- ▶ Secure the spare wheel to prevent it sliding away.
- ▶ Close the pallet storage box (see "5.17 Pallet storage box", pg. 48).
- ✓ The spare wheel is inserted.

5.15.4 Changing the spare wheel

⚠ WARNING

Risk of accident caused by loose wheel nuts!

Wheel nuts that are not tightened correctly will come loose during travel, possibly leading to serious accidents.

- ▶ Tighten the wheel nuts with the appropriate tightening torque.
- ▶ Check the tightness of the wheel nuts after each wheel change, and again shortly after the first laden journey.

⚠ WARNING

Risk of accident due to instability and rolling away!

Unintentional trailer movements can cause serious injury and property damage.

- ▶ Secure the trailer against rolling away by applying the parking brake.
- ▶ Use the wheel chocks to prevent the trailer from rolling away.
- ▶ Park the trailer on a solid surface to avoid sinking in or tipping.
- ▶ When the trailer is hitched/unhitched, ensure stability. If necessary, use additional supports.

⚠ CAUTION

Risk of injury due to a falling spare wheel!

The weight of a falling spare wheel can cause injuries.

- ▶ Work carefully when changing a spare wheel.

INFO

The tightening torques for the wheel nuts are noted in the axle manufacturer's supplier documentation.

Removing the wheel

- ▶ Lock the tractor unit to prevent unintended movement while changing the wheel.
- ▶ Secure the tractor unit and trailer according to the regulations for moving traffic (warning sign, etc.).
- ▶ Use wheel chocks to prevent the tractor unit and trailer from rolling away (see "5.1 Using wheel chocks", pg. 20).
- ▶ Apply the parking brake on the trailer (see "5.9.2 Parking brake", pg. 35).
- ▶ Loosen the wheel nuts by one turn.
- ▶ Place the jack under the axle as close as possible to the defective wheel.
- ▶ Lift the axle with the jack until the defective wheel no longer touches the ground.
- ▶ Unscrew the wheel nuts and remove them.
- ▶ Remove the defective wheel from the axle.
- ✓ The wheel is removed.

Mounting the spare wheel

- ▶ Remove the spare wheel from the spare wheel bracket (see "5.15 Spare wheel bracket", pg. 44).
- ▶ Slide the spare wheel onto the wheel hub.
- ▶ Screw on the wheel nuts and slightly tighten.

- ▶ Lower the axle with the jack.
- ▶ Properly tighten the wheel nuts in a criss-cross pattern. Please consult the axle manufacturer's supplier documentation for the specified tightening torque.
- ▶ Insert the defective wheel in the spare wheel bracket and secure it (see "5.15 Spare wheel bracket", pg. 44).
- ✓ The spare wheel has been mounted.
- ▶ Check the tyre inflation pressure of the spare wheel used.

5.16 Storage box

⚠ WARNING

Risk of accident when driving with an open storage box!

If the storage box lid is open, objects may fall out and cause accidents.

- ▶ Only drive with the storage box closed and secured.

⚠ CAUTION

Risk of injury due to falling objects!

When the storage box is opened, objects may fall out and injure people.

- ▶ Be careful when opening the storage box and watch for falling objects.

The storage box is mounted underneath the trailer. The storage box is part of the side collision protection or replaces the side collision protection.




Fig. 5-36: Storage box

- 1 Tension lock
- 2 Spring cotter pin

Opening the storage box

- ▶ Remove the spring cotter pin.
- ▶ Open the tension locks.
- ▶ Fold the lid down.
- ✓ The storage box is open.

Closing the storage box

- ▶ Fold the lid up.
- ▶ Close the tension locks.
- ▶ Secure the tension locks with spring cotter pins.
- ✓ The storage box is closed and secured.

5.17 Pallet storage box

⚠ WARNING

Risk of accident when driving with an open pallet storage box!

If the pallet storage box lid is open, pallets may fall out and cause accidents.

- ▶ Only drive with the pallet storage box closed and secured.

NOTE

Material damage when driving on uneven ground!

When driving on uneven ground with low ground clearance, the pallet storage box can be damaged.

- ▶ When driving on uneven ground, ensure that there is sufficient ground clearance.

On KRONE trailers with pallet storage boxes, the lids of the storage boxes replace the side collision protection. The lids of the pallet storage boxes are opened and closed with tension locks. Depending on the version, they are located on top or on the side of the lid.




Fig. 5-37: Pallet storage box

- 1 Tension locks
- 2 Handles
- 3 Cover

Opening the pallet storage box




Fig. 5-38: Tension lock

- 1 Tension lock
- 2 Spring cotter pin

- ▶ Remove the spring cotter pin.
- ▶ Open the tension locks.
- ▶ Carefully fold down the lid by the handles while simultaneously sliding it into the guide rails at the bottom of the pallet storage box.
- ✓ The pallet storage box is open.

Closing the pallet storage box

- ▶ Pull out the lid from the guide rails by the handles and simultaneously fold it up carefully.
- ▶ Close the tension locks.
- ▶ Secure the tension locks with spring cotter pins.
- ✓ The pallet storage box is closed and secured.

5.18 Depots

KRONE trailers can have the following depots under the vehicle:

- Post depot (see "5.18.1 Post depot", pg. 49)
- Lath depot Lath depot
- Brackets for Multi Block beams (see "5.18.2 Bracket for Multi Block beams", pg. 50)

5.18.1 Post depot

⚠ WARNING

Risk of accident due to posts falling out!

If the retainer plate is open, or if there are fewer than three posts in the depot, the posts can fall out while driving and cause accidents.

- ▶ Ensure that there are at least three posts in the depot.
- ▶ Only drive with the lock bolts secured when up to three posts are inserted.
- ▶ Only drive with the retainer plate closed, locked, and secured.

In the post depot oriented lengthwise to the vehicle, the posts are stored next to each other in the direction of travel and secured with a retainer plate.




Fig. 5-39: Post depot

- 1 Retainer plate

Removing the posts from the depot

- ▶ Slide the retainer plate upwards and then to the side.
- ▶ Remove the posts.
- ✓ The posts have been removed from the depot.

Before each trip:

- ▶ Slide the retainer plate to the side and then downwards.
- ✓ The post depot is closed, locked, and secured.

Storing the posts in the depot

- ▶ Slide the posts into the post depot next to each other.
- ▶ Slide the retainer plate to the side and then downwards.
- ✓ The posts are stored in the post depot.
- ✓ The post depot is closed, locked, and secured.

5.18.2 Bracket for Multi Block beams

⚠ WARNING

Risk of accident due to Multi Block beams falling out!

Unsecured Multi Block beams can fall out and cause accidents.

- ▶ Drive only with properly mounted and secured Multi Block beams.

The Multi Block beams Using the Multi Block system are stored in brackets along the direction of travel. Depending on the equipment, the brackets can hold up to four Multi Block beams.




Fig. 5-40: Bracket for Multi Block beams

- 1 Spring coter pin
- 2 Bracket

Unhooking the Multi Block beams

- ▶ Remove the spring coter pin.
- ▶ Unhook the Multi Block beams and remove.
- ▶ The Multi Block beams have been unhooked .

Before each trip:

- ▶ Insert the spring coter pin.

Hooking on the Multi Block beams

- ▶ Hang the Multi Block beams on the bracket.
- ▶ Insert the spring coter pin.
- ✓ The Multi Block beam is hooked on and secured.

5.19 Tool box

⚠ WARNING

Risk of accident when driving with an open tool box!

When driving with an open tool box, objects may fall out and cause accidents.

- ▶ Only drive with the tool box closed and secured.

⚠ CAUTION

Risk of injury due to falling objects!

When the tool box is opened, objects may fall out and cause injuries.

- ▶ Be careful when opening the tool box and watch for falling objects.




Fig. 5-41: Tool box

- 1 Spring coter pin
- 2 Locking flap

Opening the tool box

- ▶ Fold up the side collision protection, if necessary (see "5.14 Side collision protection", pg. 43).

- ▶ Remove the spring cotter pin.
- ▶ Fold up the locking flap.
- ▶ Open the lid.
- ✓ The tool box is open.

Closing the tool box

- ▶ Fold up the lid.
- ▶ Fold down the locking flap.
- ▶ Secure the locking flap with a spring cotter pin.
- ▶ Fold down the side collision protection, if necessary (see "5.14 Side collision protection", pg. 43).
- ✓ The tool box is closed and secured.

5.20 Water tank

CAUTION

Health hazard due to neglected hygiene!

If the hygiene regulations are not observed, the water may be contaminated. This can result in a risk to health.

- ▶ Do not fill any fluids other than water in the water tank.
- ▶ Ensure cleanliness and hygiene.

NOTE

Material damage due to frost!

Frost can damage a filled water tank.

- ▶ Do not completely fill the water tank if there is a risk of frost.

KRONE trailers can be equipped with a water tank. The water tank is installed on the frame under the chassis and is used to transport water.




Fig. 5-42: Water tank

- 1 Filler neck with screw cap
- 2 Water tap

Using the water tank

- ▶ Fill water through the filler neck.
- ▶ Close the filler neck with the screw cap.
- ▶ Draw water using the water tap on the water tank.
- ▶ Close the water tap.

5.21 Fire extinguisher

Unmaintained and unchecked fire extinguishers may not work in an emergency and will not be able to fight any potential fires. Used fire extinguishers must be replaced after a single use. Additional instructions can be found on the housing of the fire extinguisher.




Fig. 5-43: Storage box

- 1 Quick-release fasteners

Removing the fire extinguisher from its storage box

- ▶ Release the quick-release fastener on the lid.
- ▶ Swivel the cover to the side.
- ▶ Remove the fire extinguisher.
- ✓ The fire extinguisher is removed and can be used.

Placing the fire extinguisher in the storage box

- ▶ Insert the fire extinguisher.
- ▶ Close the lid.
- ▶ Close the quick-release fasteners on the lid.
- ✓ The fire extinguisher is inserted in the storage box.

6 Superstructure operation

6.1 Board walls and posts

On KRONE trailers with building material superstructures, posts and board walls limit the load compartment.

⚠ WARNING

Risk of accident from falling loads due to unsecured posts!

Inadequately secured posts can lead to a loss of load and can therefore cause injuries and material damage.

- ▶ Lock and secure the posts before travel.

⚠ WARNING

Risk of accident due to loss of load!

If the board walls are unlocked and unsecured, load falling out while driving can result in personal injury and material damage.

- ▶ Check that the board walls are locked before every trip.

⚠ CAUTION

Risk of injury due to the board walls uncontrollably folding down!

Unlocked and unsecured board walls can suddenly fold down and cause personal injury and material damage.

- ▶ When unlocking the last lock, hold onto the board wall with one hand.

⚠ CAUTION

Self-closing posts pose a risk of injury!

When the self-closing posts are inserted, they can cause personal injury.

- ▶ Wear protective gloves.
- ▶ Ensure that your hands and fingers are not in the closing area of the posts.

⚠ CAUTION

Risk of accident when driving with folded-down board walls

Folded-down board walls pose an accident hazard due to excess width and concealed contour markings.

- ▶ Do not drive with folded-down board walls.
- ▶ Fold down board walls only for loading and unloading.

KRONE trailers with a building material superstructure have removable posts, removable board walls and, depending on the version, a Multi Rail lashing rail integrated on the floor (see "8.5.6 Multi Rail lashing rail", pg. 72). The board walls are secured on the posts with integrated board wall locks.

As an option, the board walls can also be equipped with board wall locks.

Fold down the board wall with the post (integrated board wall locks)




Fig. 6-1: Post with integrated board wall locks

1 Lever

- ▶ Swivel down the lever on the post halfway.
- ▶ Hold the board wall.
- ▶ Unlock the second lock of the board wall in the same way.
- ▶ Fully fold down the board wall.
- ✓ The board wall has been folded down.

- ▶ Swivel the lever completely down and fold down the post.
- ✓ The board wall and the post are folded down.

Using the fold-down steps

There are fold-down steps on the inside of the board walls to climb onto the superstructure (see "5.13.3 Fold-down steps", pg. 43).

- ▶ Fold in the fold-down steps again after use.

Close the board wall with the post (integrated board wall locks)

- ▶ Swivel up the post.
- ▶ Swivel up the lever on the post halfway.
- ▶ Swivel up the board wall.
- ▶ Swivel the lever completely up.
- ✓ The board wall and the post are closed and locked.

Fold down the board wall with the board wall locks




Fig. 6-2: Board wall lock

- 1 Lock for the board wall lock
- 2 Lock lever
- 3 Board wall

- ▶ Push in the lock on the board wall lock.
- ▶ Position the lock lever so that the locking pin is completely out of its guide groove.

- ▶ Hold the board wall.
- ▶ Unlock the second lock on the other side of the vehicle in the same way.
- ▶ Partly fold down the board wall.
- ▶ Close both locks again.
- ▶ Fully fold down the board wall.
- ✓ The board wall has been folded down.

Using the fold-down steps

There are fold-down steps on the inside of the board walls to climb onto the superstructure (see "5.13.3 Fold-down steps", pg. 43).

- ▶ Fold in the fold-down steps again after use.

Closing the board wall

- ▶ Swivel up the board wall.
- ▶ Engage the locks on both sides of the vehicle to lock the board wall.
- ✓ The board wall is closed.

Removing the board wall

⚠ CAUTION

Risk of injury due to improper removal of the board walls!

When they are being removed, the board walls can fall down and injure people and cause material damage.

- ▶ Always remove the board wall with the help of a second person.

⚠ CAUTION

Risk of accident when driving with removed board walls

Removed board walls pose an accident hazard due to missing contour markings.

- ▶ Drive with removed board walls only if the trailer is authorised for driving without board walls.

INFO

If lighting equipment is fitted to the board walls when they are removed (e.g. edge markers), these must be reproduced on the vehicle.

- ▶ For loads with an excessive length, the board wall can be removed.
- ▶ Fold the board wall down by approximately 135°.




Fig. 6-3: Folding down the board wall

- ▶ With a second person, slide off the board wall to the right.
- ✓ The board wall has been removed.

Inserting the board wall

- ▶ With a second person, slide the board wall onto the hinges from the right-hand side.
- ▶ Fold up the board wall.
- ✓ The board wall has been inserted.

6.2 Rear wall**⚠ WARNING****Risk of accident due to loss of load!**

If the rear wall is unlocked and unsecured, load falling out while driving can result in personal injury and material damage.

- ▶ Check that the rear wall is locked before every trip.

⚠ CAUTION**Risk of injury due to the rear wall uncontrollably folding down!**

An unlocked and unsecured rear wall can suddenly fold down and cause personal injury and material damage.

- ▶ When unlocking the last lock, hold onto the rear wall with one hand.

⚠ CAUTION**Risk of accident due to folded-down rear wall!**

A folded-down rear wall can cover the lighting equipment. This can cause rear-end collisions while driving and with parked trailers, causing material damage and personal injuries.

- ▶ Drive and park only with a properly closed and secured rear wall.

Depending on the version, the rear wall of the KRONE trailer is equipped with between two and four locks.


Folding down the rear wall

Fig. 6-4: Rear wall lock

- 1 Lock for the rear wall lock
- 2 Lock lever
- 3 Board wall

- ▶ Push in the lock on the rear wall lock.
- ▶ Position the lock lever so that the locking pin is completely out of its guide groove.
- ▶ Hold onto the rear wall.

- ▶ Unlock the second lock on the other side of the vehicle in the same way.
- ▶ Partly fold down the rear wall.
- ▶ Close both locks again.
- ▶ Fully fold down the rear wall.
- ✓ The rear wall has been folded down.

Using the fold-down steps

There are fold-down steps on the inside of the rear wall to climb onto the superstructure (see "5.13.3 Fold-down steps", pg. 43).

- ▶ Fold in the fold-down steps again after use.

Closing the rear wall

- ▶ Swivel up the rear wall.
- ▶ Engage the locks on both sides of the vehicle to lock the rear wall.
- ✓ The rear wall is closed.

Removing the rear wall

⚠ WARNING

Danger when transporting loads of excessive length!

Transporting protruding load parts can result in accidents with material damage and injure people.

- ▶ Restrict the size of the protrusion.
- ▶ Mark the load with excessive length using a red flag, for example.

⚠ CAUTION

Risk of injury due to improper removal of the rear wall!

When it is being removed, the rear wall can fall down and injure people and cause material damage.

- ▶ Always remove the rear wall with the help of a second person.

INFO

If lighting equipment is fitted to the rear wall when it is removed (e.g. edge markers), these must be reproduced on the vehicle.

For loads of excessive length, the rear wall can be removed.




Fig. 6-5: Folding down the rear wall

- ▶ Fold the rear wall down by approximately 135°.
- ▶ With a second person, slide off the rear wall to the right.
- ✓ The rear wall has been removed.

Inserting the rear wall

INFO

The rear wall can only be inserted in the same position as it was removed.

- ▶ With a second person, slide the rear wall onto the hinges from the right-hand side.
- ▶ Fold up the rear wall.
- ✓ The rear wall has been inserted.

6.3 Door retainer chain

⚠ WARNING

Danger when transporting loads of excessive length!

Transporting protruding load parts can result in accidents with material damage and injure people.

- ▶ Restrict the size of the protrusion.
- ▶ Mark the load with excessive length using a red flag, for example.

⚠ CAUTION

Risk of accidents due to unsecured chains!

Unsecured chains can swing about while driving and injure people and cause material damage.

- ▶ When not in use, always place the chains over the rear wall into the load compartment.

For loads of excessive length, it is possible to partly open the rear wall and hold it in position with retainer chains.

Hooking on the door retainer chain

- ▶ Fold down the rear wall to the horizontal position.
- ▶ Hook the door retainer chain onto the bracket.
- ✓ The door retainer chain is hooked on.

Securing the door retainer chain

- ▶ When driving, place the door retainer chain over the rear wall into the load compartment.
- ✓ The door retainer chain is secured.

6.4 Mobile front wall

The turnframe version of KRONE trailers can be equipped with a mobile front wall. The mobile front wall can be used as a load compartment partition transverse to the direction of travel, thereby preventing the load from sliding along the length of the trailer. The front wall can be placed in

many positions using the plug-in posts. This ensures that positive-locking load securing in the direction of travel is achieved with rear partial loads (e.g., after partially unloading the front load compartment). When not in use, the mobile front wall is locked in the foremost position behind the fixed front wall.




Fig. 6-6: Mobile front wall

- 1 Front wall
- 2 Mobile front wall
- 3 Plug-in posts




Fig. 6-7: Mobile front wall in the foremost position

- 1 Front wall
- 2 Mobile front wall
- 3 Post socket for mobile front wall
- 4 Plug-in posts

Positioning the mobile front wall

⚠ WARNING

An unhooked mobile front wall is an accident risk!

An unhooked mobile front wall does not fully secure the load. Load falling out can cause personal injury as well as material damage.

- ▶ Do not exceed the 7 t payload when using the mobile front wall.
- ▶ Secure the mobile front wall with the fastening hooks before every trip.




Fig. 6-8: Mobile front wall fastening hooks

- 1 Mobile front wall
- 2 Fastening hooks
- 3 Plug-in post

- ▶ Lift the mobile front wall and unhook the fastening hooks.
- ▶ Set the front wall down.
- ▶ Remove the plug-in posts.
- ▶ Reinsert the plug-in posts in the post sockets at the required position.




Fig. 6-9: Bracket on plug-in post

- 1 Plug-in post
- 2 Bracket

- ▶ Place the front wall on the plug-in posts and lift it into the brackets.
- ▶ Hook both fastening hooks.
- ✓ The mobile front wall is positioned.
- ▶ When not in use, place the mobile front wall back in the foremost position.

6.5 Front wall depot for edge protectors

Depending on the version, KRONE trailers can be equipped with a front wall depot. It comprises four depot rods that are used to store the edge protectors.




Fig. 6-10: Front wall depot for edge protectors

- 1 Depot
- 2 Edge protectors

Storing the edge protectors in the depot**⚠ WARNING****Risk of accident due to loss of the edge protectors!**

An unsecured front wall depot can cause the edge protectors to fall out while driving and injure people and cause material damage.

- ▶ Insert all spring cotter pins before each trip.

INFO

Depending on the manufacturer, holes may need to be drilled into the edge protection in order to fasten them onto the depot rods. While doing so, pay attention to the spacing of the depot rods.




Fig. 6-11: Store the edge protectors

- 1 Spring cotter pin
- 2 Depot rods
- 3 Edge protectors

- ▶ Remove the spring cotter pin.
- ▶ Hook the edge protectors into the depot rods.
- ▶ Insert the spring cotter pin.
- ✓ The edge protectors are stored in the depot.

Removing the edge protectors from the depot

- ▶ Remove the spring cotter pin.

- ▶ Remove the required amount of edge protectors.
- ▶ Insert the spring cotter pin.
- ✓ The edge protectors have been removed from the depot.

7 Road operations

7.1 Commissioning before each trip

Commissioning before each trip ensures road safety and includes a check before driving off and after loading and unloading. Perform a departure check prior to starting each trip:

- Are the documents for the tractor unit and trailer at hand?
- Are the tractor and trailer in the combination suitable for the transport task?
- Is there sufficient clearance between the vehicles so that the connection lines are not functionally impaired and can move freely?
- Are the applicable regulations for driving on public roads observed with the transport tasks?
- Have all accident prevention regulations been complied with?
- Are all the supply and control connections properly made between the tractor and the trailer?
- Is the trailer coupling locked and secured correctly?
- Has the functional test of the EBS brake system been audibly heard?
- Are all the vehicle components (such as wheel chocks, storage boxes, landing leg winches) present, properly fastened or respectively closed and secured?
- Are all movable collision protections locked and secured?
- Is the load properly distributed and correctly secured?
- Has the permitted maximum total weight been adhered to?
- Is there sufficient clearance between the vehicle floor and the tyres?
- Is the air suspension in the driving position?

- Is the permitted vehicle height complied with?
- Are lighting and signalling systems fully operational?
- Are the tyres inflated to the correct pressure?
- Has the trailer's parking brake been disengaged?
- Is the compressed air supply for the trailer's brakes sufficient?
- Are the landing leg winches retracted and secured?
- Are the compressed air tanks drained?
- Does the warning lamp/warning display in the tractor indicate that the trailer's braking system is error free?
- ▶ Fix any observed defects.
- ▶ Only drive the tractor unit and trailer when road safety is ensured.

7.2 Hitching and unhitching the trailer

DANGER

Danger to life due to crushing!

People can be crushed between the tractor unit and trailer when hitching and unhitching.

- ▶ Instruct persons to leave the danger area between tractor unit and trailer.
- ▶ Ensure that any guide person present stays far enough away to the side from the vehicles.

CAUTION

Risk of injury due to uncontrolled movement of the draw fork

Upon releasing the front axle brakes, the draw fork can suddenly swing sideways if the wheels of the front axle are not placed on a level, smooth ground surface.

- ▶ Park the trailer on solid and level ground to prevent the draw fork from moving uncontrollably.

NOTE**Material damage due to improper hitching and unhitching**

Improper hitching and unhitching can cause damage to the trailer.

- ▶ Before hitching and unhitching, set the trailer's draw gear to the corresponding height of the tractor unit's trailer coupling.
- ▶ When hitching and unhitching, also observe the instructions from the tractor unit's operating instructions.

INFO

More information is available from the enclosed supplier documentation and BG information "Safe coupling of trailers".




Fig. 7-1: Coupling ring

1 Coupling ring

Hitching the central axle trailer

- ▶ Before coupling, check:
 - Is the tractor unit's permissible towing capacity adequate for the trailer?
 - Has the permissible drawbar load been observed?
 - Has the permitted maximum length been observed?
 - Do the tractor unit's trailer coupling design and the trailer's coupling eye design match?
 - Do the position of the draw gear and the coupling height match?

- ▶ Apply the parking brake on the trailer (see "5.9.2 Parking brake", pg. 35).
- ▶ Use wheel chocks to prevent the trailer from rolling away (see "5.1 Using wheel chocks", pg. 20).
- ▶ Move the tractor unit towards the coupling ring, leave approx. 1 m distance.
- ▶ Set the height of the coupling ring to the centre of the coupling funnel or to the height of the lowest lip on the coupling funnel.
- ▶ Use the coupling's hand lever to move the coupling bolts to the "opened" position.
- ▶ Lock the coupling funnel in open position.
- ▶ Vacate the danger area between the tractor unit and trailer!
- ▶ Begin coupling by backing up the tractor unit. The coupling automatically takes place.
- ▶ Apply the parking brake on the tractor unit (see "5.9.2 Parking brake", pg. 35).
- ▶ Check if the coupling bolt is properly locked into place.
- ▶ Connect the supply and control lines (see "5.6 Supply and control connections", pg. 29).
- ▶ Retract the landing leg winches (see "5.2 Landing leg winches", pg. 21).
- ▶ Remove the wheel chocks and properly secure them (see "5.1 Using wheel chocks", pg. 20).
- ▶ Disengage the parking brake on the trailer (see "5.9.2 Parking brake", pg. 35).
- ▶ Set the air suspension to the driving position (see "5.10 Air suspension", pg. 39).
- ▶ Carry out a departure check (see "7.1 Commissioning before each trip", pg. 60).
- ✓ The central axle trailer is hitched and ready to drive.

Unhitching the central axle trailer

INFO

After uncoupling the brake lines, close off the coupling heads and the connection sockets for the electrical cables/power to prevent contamination.

- ▶ Position the train as straight as possible.
- ▶ Apply the parking brake on the tractor unit.
- ▶ Apply the parking brake on the trailer (see "5.9.2 Parking brake", pg. 35).
- ▶ Use wheel chocks to prevent the trailer from rolling away (see "5.1 Using wheel chocks", pg. 20).
- ▶ Wind down the landing leg winch until the coupling ring is slightly lifted off the coupling funnel (see "5.2 Landing leg winches", pg. 21).
- ▶ Disconnect the supply and control lines (see "5.6 Supply and control connections", pg. 29).
- ▶ Use the coupling's hand lever to move the coupling bolts to the "opened" position.
- ▶ Slowly drive the tractor unit away in a straight line.
- ▶ Use the coupling's hand lever to move the coupling bolts to the "closed" position.
- ✓ The central axle trailer is unhitched.

Hitching the turnframe trailer

- ▶ Before coupling, check:
 - Is the tractor unit's permissible towing capacity adequate for the trailer?
 - Has the permissible drawbar load been observed?
 - Has the permitted maximum length been observed?
 - Do the tractor unit's trailer coupling design and the trailer's coupling eye design match?
 - Do the position of the draw gear and the coupling height match?
- ▶ Apply the parking brake on the trailer (see "5.9.2 Parking brake", pg. 35).
- ▶ Use wheel chocks to prevent the trailer from rolling away (see "5.1 Using wheel chocks", pg. 20).
- ▶ Release the front axle brake.
- ▶ Move the tractor unit towards the coupling ring, leave approx. 1 m distance.
- ▶ Set the coupling ring of the draw fork to the coupling height (see "5.4 Draw fork", pg. 25).
- ▶ Use the coupling's hand lever to move the coupling bolts to the "opened" position.
- ▶ Lock the coupling funnel in open position.
- ▶ Vacate the danger area between the tractor unit and trailer!
- ▶ Begin coupling by backing up the tractor unit. The coupling automatically takes place.
- ▶ Apply the parking brake on the tractor unit (see "5.9.2 Parking brake", pg. 35).
- ▶ Check if the coupling bolt is properly locked into place.
- ▶ Connect the supply and control lines (see "5.6 Supply and control connections", pg. 29).
- ▶ If necessary, release the height adjustment device.
- ▶ Remove the wheel chocks and properly secure them (see "5.1 Using wheel chocks", pg. 20).
- ▶ Disengage the parking brake on the trailer (see "5.9.2 Parking brake", pg. 35).
- ▶ Set the air suspension to the driving position (see "5.10 Air suspension", pg. 39).
- ▶ Carry out a departure check (see "7.1 Commissioning before each trip", pg. 60).
- ✓ The turnframe trailer is hitched and ready for travel.

Unhitching the turnframe trailer

INFO

After uncoupling the brake lines, close off the coupling heads and the connection sockets for the electrical cables/power to prevent contamination.

- ▶ Position the train as straight as possible.
 - ▶ Apply the parking brake on the tractor unit.
 - ▶ Apply the parking brake on the trailer (see "5.9.2 Parking brake", pg. 35).
 - ▶ Use wheel chocks to prevent the trailer from rolling away (see "5.1 Using wheel chocks", pg. 20).
 - ▶ If necessary, arrest the height adjustment device.
 - ▶ Disconnect the supply and control lines (see "5.6 Supply and control connections", pg. 29).
 - ▶ Use the coupling's hand lever to move the coupling bolts to the "opened" position.
 - ▶ Slowly drive the tractor unit away in a straight line.
 - ▶ Use the coupling's hand lever to move the coupling bolts to the "closed" position.
- ✓ The turnframe trailer is unhitched.

7.3 Manoeuvring the trailer without a connected compressed air supply

INFO

Manoeuvring without a connected compressed air supply is only permissible in exceptional cases.

To manoeuvre the trailer without a connected compressed air supply, the service brake (see "5.9.1 Service brake", pg. 35) must be released.




Fig. 7-2: Control unit for brake system of central axle trailer

- 1 Red control knob for the parking brake
- 2 Black control knob for the service brake




Fig. 7-3: Control unit for brake system of turnframe trailer

- 1 Red control knob for the parking brake
- 2 Black control knob for the service brake

- ☑ The trailer's compressed air supply is not connected.
- ▶ Press in the black control knob for the service brake.
- ▶ Press in the red control knob for the parking brake (see "5.9.2 Parking brake", pg. 35).
- ▶ The trailer brake is released.
- ✓ The trailer can be manoeuvred.
- ▶ Pull out the black control knob for the service brake again after manoeuvring.

- ▶ Pull out the red control knob for the parking brake.
- ✓ The trailer brake is engaged.

7.4 Parking the trailer safely

⚠ WARNING

Risk of accident due to instability and rolling away!

Unintentional trailer movements can cause serious injury and property damage.

- ▶ Secure the trailer against rolling away by applying the parking brake.
- ▶ Use the wheel chocks to prevent the trailer from rolling away.
- ▶ Park the trailer on a solid surface to avoid sinking in or tipping.
- ▶ Align the tractor unit and trailer behind each other in a straight line.
- ▶ Load and unload the trailer such that traffic hazards are ruled out.
- ▶ Be mindful of the trailer's stability when loading and unloading while unhitched. If necessary, use additional supports.

INFO

Ramp adjustments can only be made in the coupled (saddled) condition, with added compressed air. If rear braces have been factory-fitted to the rear of the trailer, adjust these according to the height of the ramp.

- ▶ Drive the trailer onto firm and level ground.
- ▶ Apply the parking brake (see "5.9.2 Parking brake", pg. 35).
- ▶ Use wheel chocks to prevent the trailer from rolling away (see "5.1 Using wheel chocks", pg. 20).
- ▶ Extend the landing leg winches (see "5.2 Landing leg winches", pg. 21).
- ▶ Extend the rear braces, if present (see "5.3 Rear braces", pg. 23).

- ▶ Disconnect the supply and control connections (see "5.6 Supply and control connections", pg. 29).
- ▶ Unhitch the trailer from the tractor unit.
- ▶ For longer parking periods and when loading the ramp while parked, lower the air suspension (see "5.10 Air suspension", pg. 39).
- ✓ The trailer is safely parked.

8 Loading and securing

WARNING

Risk of accident due to instability and rolling away!

Unintentional trailer movements can cause serious injury and property damage.

- ▶ Secure the trailer against rolling away by applying the parking brake.
- ▶ Use the wheel chocks to prevent the trailer from rolling away.
- ▶ Park the trailer on a solid surface to avoid sinking in or tipping.
- ▶ Align the tractor unit and trailer behind each other in a straight line.
- ▶ Load and unload the trailer such that traffic hazards are ruled out.
- ▶ Be mindful of the trailer's stability when loading and unloading while unhitched. If necessary, use additional supports.

WARNING

Risk of accident due to overloaded trailer!

Driving with an overloaded trailer can result in serious accidents with personal injury and material damage to the tractor and the trailer.

- ▶ Evenly distribute the load.
- ▶ Observe the legally permitted values for the total weight as well as axle and drawbar loads.
- ▶ Observe the trailer's maximum permitted axle loads. In case of doubt, have the axle loads checked at a suitable weighing station.
- ▶ Comply with current national and international regulations on load securing.

WARNING

Risk of accident caused by incorrect loading and unloading!

Incorrect loading and unloading of the load can result in accidents with personal injury and material damage.

- ▶ Evenly load and unload the trailer. The centre of gravity must lie on the trailer's longitudinal centre line.
- ▶ Distribute the load as low as possible on the load compartment floor.
- ▶ Observe the permissible total weight, permissible axle and drawbar loads along with the maximum height.
- ▶ Ensure that the cargo can withstand the loads from stacking, transport, and the load securing system.

WARNING

Risk of accident caused by sliding and tipping loads!

When driving, slipping or tipping of the load can result in personal injury and damage to property.

- ▶ Secure the load with suitable means to prevent it from sliding and tipping.

CAUTION

Risk of accident due to improper securing of the load!

Improper securing of the load can result in accidents with personal injury and material damage.

- ▶ Secure the load with lashing material.
- ▶ Do not nail the cargo to the load compartment.

NOTE**Material damage due to trailer rebound during unloading!**

When the trailer is unloaded, the suspension decompresses. As a result, headroom heights may then be insufficient.

- ▶ When unloading trailers in underpasses or in factory halls, observe the headroom.

NOTE**Material damage when loading and unloading with forklifts!**

Loading and unloading with a forklift can exceed the bearing capacity of the load compartment floor and result in material damage.

- ▶ Observe the permissible working load limit of the load compartment floor.
- ▶ Observe the permissible inner dimensions of the load compartment with a loaded forklift.

NOTE**Material damage to floor due to improper loading!**

On trailers with an anti-slip coating (Trailer Safety Floor), loads sliding across the floor can cause material damage due to excess wear.

- ▶ Do not slide the load across the floor.
- ▶ Lift the load to move it.

INFO

The axle loads can vary due to the various loading conditions of the trailer. Information on the permitted axle loads can be obtained either from the type plate or the vehicle documents.

INFO

Keep the inspection booklet in the vehicle as proof of the validity of the load securing certificate. The inspection booklet serves as proof of the trailer's maintenance condition and can be downloaded from the download section at www.krone-trailer.com.

The required securing is partially achieved through friction between the load and the load compartment. A rough load on a rough load compartment reduces the need for additional securing equipment.

However, even with high friction values, securing the load is essential. When driving, trailers and the load can start vibrating, which reduces or eliminates the friction.

For loading and unloading, the trailer must be

- hitched and secured, or
- unhitched and supported.

8.1 Using straps**⚠ CAUTION****Risk of accident caused by incorrect use of straps!**

When the cargo shifts while driving, e.g. due to vibrations, strapping can lose its tension and become loose. Incorrect securing of the load can result in accidents with personal injury and material damage.

- ▶ Apply down-strapping to the support points of the cargo.

NOTE**Material damage caused by incorrect use of straps!**

Incorrect use of lashing belts, chains or wire ropes can result in material damage to the cargo.

- ▶ Only load lashing equipment at the maximum permitted values.
- ▶ Immediately replace defective or damaged straps.
- ▶ Have repairs on straps carried out by qualified staff.
- ▶ Never tension straps and ratchets over sharp edges.
- ▶ Do not use straps to lift cargo.
- ▶ Do not place any cargo on the straps.
- ▶ Do not twist or knot the straps.
- ▶ Do not use ratchet extensions, except on heavy-duty ratchets designed for this purpose.

NOTE**Material damage caused by uneven tension force!**

If the load is strapped down unevenly and/or the lashing down is done with large clamping forces, this can result in material damage.

- ▶ Ensure that the pre-tension force is evenly distributed on both sides of the load.
- ▶ Apply the ratchets on alternate sides when using tie-down lashing.
- ▶ For pressure-sensitive cargo (e.g. beverage crates) that cannot be subjected to high securing forces, use large-sized angular rails. This allows higher pre-tension forces to be applied without damaging the cargo.

Tie-down lashing, angular lashing, and diagonal lashing can be achieved with lashing material such as lashing belts, lashing chains, and lashing cables.




Fig. 8-1: Lashing material

- 1 Wire hook
- 2 Lashing belts
- 3 Flat hook




Fig. 8-2: Lashing chain with load hook

- 1 Lashing chain
- 2 Load hook

Wire hooks, flat hooks, and load hooks can be used to fasten the straps.

With tie-down lashing, the securing effect is achieved by increasing the pressure against the load compartment. Angled and diagonal lashing prevents non-stable loads from tipping over.




Fig. 8-3: Strap ratchet

The straps are tensioned using suitable clamping devices, such as strap ratchets or lashing strap winches.

Lashing down the load

- ▶ Attach the hooks on the lashing belts or lashing chains to the opening on the lashing rail.
- ▶ Move the lashing belts to the required position and allow them to engage
- ▶ Tighten the lashing belts.
- ✓ The load is lashed down.

8.2 Ensuring form-fitting

NOTE

Material damage caused by empty spaces in the cargo area!

Empty spaces between parts of the cargo can result in material damage to the load while driving.

- ▶ Eliminate any empty space towards the cargo space limiters.
- ▶ Eliminate any empty space between individual pieces of cargo.
- ▶ Comply with the permissible axle load when eliminating empty spaces.
- ▶ Fill empty spaces for example with wooden pallets, storage pads or air cushions.
- ▶ Fill stowage gaps in the middle with packs of wood chip for example.
- ▶ Secure the load, e.g. by lashing it down.

Flush loading and form-fitting makes load securing easier. Form-fitting load securing means that the load fills the space between the load compartment limiters at the front, side, and rear wall.

8.3 Securing pallets with hoop casings and shrink-wrap

Fastening hoops and plastic foil shrink-wrap of load items placed on pallets are not intended for load securing. They only fasten the load onto or with the pallet.

- ▶ Secure the load with hoop casings and shrink-wrap on pallets against sliding, e.g. by lashing it down (see "8.1 Using straps", pg. 66).

8.4 Securing loads with tension chains to centre posts/ board walls

KRONE trailers have tension chains as an option, which are used to ease the pressure on the centre posts and board walls and to counter increased load pressure.




Fig. 8-4: Using tension chains

- 1 Tension chains with tension lever

Tension is achieved via two chain halves fastened on two posts facing each other, and being connected and tensioned in the centre of the vehicle.

The tension chains are handled in the same way for centre posts and board walls.

Connecting the tension chains

- ▶ Insert the ends of the tension chains with the fastening link in the brackets on the posts.
- ▶ Insert the tension lever of one chain through a chain link of the other chain.
- ▶ Hook the tension lever onto the fastening chain link.
- ▶ Fold and secure the tension lever.
- ✓ The tension chains have been tied and tensioned.

Releasing the tension chains

- ▶ Unhook the tension lever from the fastening link.
- ▶ Separate both tension chains from each other.
- ✓ The tension chains have been released.

8.5 Using the Multi Safe system

The Multi Safe system includes various load securing systems with which the KRONE trailer can be equipped. Information on the Multi Safe systems will be provided below.

8.5.1 Using the Multi-Lock external frame

KRONE trailers are equipped with a Multi-lock external frame with universal load security possibilities. The lashing holes are distributed along the whole length of the vehicle at 100-mm intervals. The Multilock external frame can support loads of 2,000 daN (~kg) per lashing hole, with a maximum total load of 8,000 daN (~kg) over a length of 1,000 mm.




Fig. 8-5: Multilock external frame

- 1 Lashing hole

Other load securing systems can be fastened in the Multi Lock external frame, e.g. Multi Block or Multi Wall.

8.5.2 Using the Multi Lash lashing rings

KRONE trailers can be equipped with Multi Lash lashing rings. The pivoting lashing rings allow a tension strap to be attached above the exterior frame and thus, even extremely flat loads can be secured.




Fig. 8-6: Multi Lash with Multilock external frame

- 1 Multi Lash lashing ring
- 2 Hole

The Multi Lash lashing rings can be flexibly screwed into the existing holes in the Multi-lock external frame (see "8.5.1 Using the Multi-Lock external frame", pg. 69). Multi Lash can support loads up to 2,000 daN.

8.5.3 Using the Multi Flex chain adapter

KRONE trailers can be equipped with Multi Flex chain adapters. The chain adapter enables the use of many different hook shapes on the lashing belts and lashing chains.




Fig. 8-7: Multi Flex chain adapter with Multilock external frame

The Multi Flex chain adapter is locked with two hooks onto the Multi Lock external frame (see "8.5.1 Using the Multi-Lock external frame", pg. 69). It can sustain loads up to 4,000 daN.

Inserting the Multi Flex chain adapter




Fig. 8-8: Multi Flex chain adapter

- 1 Hook mount
- 2 Hook for Multi Flex chain adapter

- ▶ Attach the hook for the Multi Flex chain adapter to the lashing holes on the Multilock external frame.

- ▶ Attach the lashing belt hook to the hook mount of the Multi Flex chain adapter.
- ✓ The Multi Flex chain adapter has been inserted.

8.5.4 Using the Multi Flex Flat chain adapter

KRONE trailers can be equipped with Multi Flex Flat chain adapters. A chain adapter for flat lashing allows the tension straps to be attached above the Multi Lock external frame (see "8.5.1 Using the Multi-Lock external frame", pg. 69) and therefore allows you to secure extremely flat loads, e.g. heavy packages of sheet metal.




Fig. 8-9: Multi Flex Flat chain adapter

- 1 Lashing eyelet

The Multi Flex Flat chain adapter is locked onto the Multi Lock external frame. It can sustain loads up to 4,000 daN.

Inserting the Multi Flex Flat chain adapter

- ▶ Lock the Multi Flex Flat chain adapter onto the Multi Lock external frame.
- ▶ Hook the lashing belt onto the lashing eyelet of the Multi Flex Flat chain adapter.
- ✓ The Multi Flex Flat chain adapter has been inserted.

8.5.5 Using the Multi Fix system

KRONE trailers can be equipped with the Multi Fix load securing system. The Multi Fix system secures pipes, round steels, or sheets with a load weight up to 25 t. The Multi Fix system consists of footing beams, sliding shoes, support beams, and one or two safety nets. The footing beam is split into two parts and is attached during installation. The footing beams can be variably fastened to the Multilock external frame (see "8.5.1 Using the Multi-Lock external frame", pg. 69). The footing beams either have a lock lever or a screw for securing the system to the vehicle floor.




Fig. 8-10: Multi Fix system

Installing the Multi Fix system




Fig. 8-11: Installing the Multi Fix system

- 1 Footing beam with lock lever
- 2 Sliding shoe
- 3 Support beam

- 4 Sliding shoe
- 5 Footing beam without lock lever
- 6 Lock lever on footing beam

- ▶ Hook the footing beam without lock lever onto the lashing holes on the Multi Lock external frame (see "8.5.1 Using the Multi-Lock external frame", pg. 69).




Fig. 8-12: Multi Fix footing beam

- 1 Connection profile on footing beam with lock lever
- 2 Connection profile on footing beam

- ▶ Attach the footing beam with the lock lever to the lashing holes on the opposite side on the Multi Lock external frame (see "8.5.1 Using the Multi-Lock external frame", pg. 69).




Fig. 8-13: Lock lever secured on the footing beam

- 1 Lock lever
- 2 Eyelet on lock lever
- 3 Hook on footing beam without lock lever

- ▶ Open the lock lever.
- ▶ Assemble the connection profiles.
- ▶ Attach the hook on the lock lever to the hook on the footing beam without lock lever.
- ▶ Close the lock lever.
- ▶ Place the sliding shoes on the footing beam in the required position and allow them to engage.




Fig. 8-14: Sliding shoe secured with plug-in bolt and spring cotter pin

- 1 Spring cotter pin
- 2 Plug-in bolt
- 3 Sliding shoe

- ▶ Insert the plug-in bolt into the hole.

- ▶ Secure the plug-in bolt with a spring cotter pin.
- ▶ Insert the support beam vertically into the sliding shoes.
- ✓ The Multi Fix system has been inserted.

Securing steel pipes with the Multi Fix system

- ▶ Position the steel pipes on the footing beam between the vertical support beams (see "Fig. 8-10: Multi Fix system", pg. 71).
- ▶ Install the safety net at the ends of the steel pipe (see "Fig. 8-10: Multi Fix system", pg. 71).
- ▶ Pull the tension straps through the eyelets of the safety nets.
- ▶ Hook the tension straps onto the Multi-lock external frame.
- ▶ Lash the tension straps.
- ✓ The steel pipes are secured.

8.5.6 Multi Rail lashing rail

The Multi Rail lashing rail is integrated into the centre of the floor of building material trailers and runs continuously over the entire length of the trailer.




Fig. 8-15: Multi Rail lashing rail

- 1 Multi Rail lashing rail

The lashing rail has two lashing points every 100 mm, each with 2,000 daN lashing load. The load may not exceed 8,000 daN in total across a length of 1,000 mm.

9 Troubleshooting in the event of faults

⚠ WARNING

Risk of accident due to instability and rolling away!

Unintentional trailer movements can cause serious injury and property damage.

- ▶ Secure the trailer against rolling away by applying the parking brake.
- ▶ Use the wheel chocks to prevent the trailer from rolling away.
- ▶ Park the trailer on a solid surface to avoid sinking in or tipping.
- ▶ Ensure stability when the trailer is unhitched. If necessary, use additional supports.

⚠ WARNING

Risk of accident and material damage caused by improperly performed troubleshooting and repair work!

Improperly performed troubleshooting and repair work affect safety and may lead to serious injuries and property damage.

- ▶ Only have necessary repair work performed by an authorised specialist workshop.
- ▶ Only use original spare parts and spare parts authorised by KRONE.
- ▶ Observe the instructions concerning troubleshooting issued by the suppliers of the installed components.
- ▶ Verify functionality after installing/repairing components.

The following overview will help to determine possible faults and their causes and to perform measures to eliminate them. In case of faults that cannot be fixed:

- ▶ Visit an authorised specialist workshop.
- ▶ Contact the customer service department of Fahrzeugwerk Bernhard KRONE GmbH & Co. KG (see "12.2 Customer service and support", pg. 88).

Troubleshooting overview

Fault	Cause	Solution
Electrical components are not working	Supply and control connections are interrupted	▶ Check that the supply and control connections between the tractor unit and trailers are properly connected.
Pneumatic components are not working	Leaks on components	▶ Check the components for damage and leaks. ▶ Have repairs/replacements performed by a specialist workshop.
Brake system fault	Leaks on the brake cylinder, leaks on the brake calliper	▶ Check the brake cylinders for function and leaks. ▶ Check the brake callipers for function and leaks. ▶ Have repairs/replacements performed by a specialist workshop. ▶ In addition to the operating instructions for the KRONE Trailer Axle, also observe the operating instructions for the tractor unit and the trailer.

Fault	Cause	Solution
Braking abnormalities (trailer and tractor brake abnormally in the vehicle combination)	Failure to perform the brake power/train tuning	<ul style="list-style-type: none"> ▶ Perform a brake power/train tuning with the allocated tractor unit (see "9.2 Fixing braking abnormalities", pg. 74). ▶ In addition to the operating instructions for the KRONE Trailer Axle, also observe the operating instructions for the tractor unit and the trailer.
ABS/EBS error display	Fault in the controller	<ul style="list-style-type: none"> ▶ Contact an authorised specialist workshop or customer service.
Rear lights, direction indicators, position lamps or similar do not work	Defective bulbs	<ul style="list-style-type: none"> ▶ Replace the defective bulbs. ▶ Check that the supply and control connections between the tractor and trailer are properly connected.
The lift axle no longer functions	<ul style="list-style-type: none"> ○ Faults on the lift axle control due to defective lift axle valves ○ Fault due to incorrect controls from the tractor unit 	<ul style="list-style-type: none"> ▶ Check that the supply and control connections between the tractor unit and trailers are properly connected. ▶ Contact an authorised specialist workshop or customer service.

9.1 Checking the lift axle control

⚠ WARNING

Risk of accident caused by faulty lift axle control!

A faulty lift axle control can have negative effects on the handling characteristics of the trailer. It can also change the vehicle height or the distance from the road and cause the trailer to get stuck in underpasses.

- ▶ Only drive with properly functioning lift axle control.
- ▶ In case of malfunction, contact an authorised specialist workshop and have the lift axle control repaired.

- ▶ In case of faults, have the lift axle control inspected by an authorised specialist workshop.

9.2 Fixing braking abnormalities

⚠ WARNING

Risk of accidents due to incorrect brake tuning!

Incorrect brake tuning between tractor unit and trailer can result in serious accidents.

- ▶ If necessary, carry out a brake power/train tuning to obtain optimum brake balance.
- ▶ Observe the reference brake values.
- ▶ Pay attention to the sticker on the trailer.

Technically optimised function of the brake system is only possible when trailer is combined with the corresponding allocated tractor unit. All components and the con-

trols must function without faults and be properly set. If braking abnormalities occur, the following apply:

- ▶ Fill in the following questionnaire for basic information regarding braking abnormalities and send it to KRONE.
- ▶ More information and instructions can be found on the KRONE website or requested from customer service (see *"12.2 Customer service and support"*, pg. 88).
- ▶ Observe the operating and maintenance instructions of the installed supplied components.

Questionnaire: Basic information about braking abnormalities

- ▶ Copy the questionnaire below.
- ▶ Fill in the questionnaire completely.
- ▶ Include the following attachments:
 - Logs from the rolling brake test stand
 - Data from the memory of the brake electronics
 - Error memory
 - Operating data
 - If necessary, the data from the internal CPU memory (e.g. EEPROM memory for WABCO systems)

Customer	
Name/company	
Telephone	
Fax	
Email	

Trailer	
Item number	
Vehicle ID number (see "1.3 Product identification and type plate", pg. 7)	
New registration	
Trailer mileage	km
Brake pads mileage	km

Tractor unit	
Manufacturer	
Type	
New registration	km
Tractor unit mileage	km
Brake pads mileage	km

- ▶ Send the filled form and annexes to:

Fahrzeugwerk Bernard KRONE
 GmbH & Co. KG
 Customer Service
 D-49757 Werlte
 email: kd.nfz@krone.de

10 Maintenance and repair

DANGER

Risk of accident due to unintended vehicle movements!

Unintended vehicle movements can cause serious injury.

- ▶ Use wheel chocks to prevent the trailer from rolling away.
- ▶ Park the trailer on solid and level ground to avoid sinking in or tipping.
- ▶ During maintenance and repair work, observe the stability of the trailer.
- ▶ Observe the applicable national accident prevention regulations.

WARNING

Risk of accident and material damage caused by improperly performed troubleshooting and repair work!

Improperly performed troubleshooting and repair work affect safety and may lead to serious injuries and property damage.

- ▶ Only have necessary repair work performed by an authorised specialist workshop.
- ▶ Only use original spare parts and spare parts authorised by KRONE.
- ▶ Observe the instructions concerning troubleshooting issued by the suppliers of the installed components.
- ▶ Verify functionality after installing/repairing components.

Maintenance and repair serve to maintain the operational readiness and to prevent premature wear. Maintenance is divided into:

- Care and cleaning
- Maintenance
- Repair

10.1 Care and cleaning

NOTE

Material damage caused by incompatible cleaning agent

Incompatible cleaning agents can damage the paintwork, metal surfaces or plastic surfaces as well as destroy lines, hoses and seals.

- ▶ Do not use aggressive cleaning agents.
- ▶ Use acid-free and pH-neutral cleaning agents.
- ▶ Do not clean brake hoses and air lines with petrol, benzene, petroleum or mineral oils.
- ▶ Only use water to remove stubborn dirt.

NOTE

Material damage caused by high-pressure cleaners!

When using a high-pressure cleaner, surfaces and components can be damaged.

- ▶ Keep a minimum distance of approx. 0.3 m between the nozzle of the high-pressure cleaner and the surface being cleaned.
- ▶ Do not aim the water jet directly at electrical components, plug connections, seals or hoses.

NOTE

Material damage caused by road salt!

The use of road salt on public roads can damage the trailer if it is not cared for properly.

- ▶ After driving on roads treated with road salt, clean the trailer immediately with lots of cold water.
- ▶ Avoid warm water because it heightens the effect of the salt.

NOTE

Environmental damage caused by chemicals!

Along with dirt, lubricants and cleaning agents can also end up in the waste water and endanger the environment when you wash your vehicle.

- ▶ Do not allow lubricants or other cleaning chemicals to escape into drains, sewers or to seep into the ground.
- ▶ Only clean in suitable washing areas with an oil separator.
- ▶ Observe the applicable national environmental protection measures.

Cleaning the trailer

- ▶ Park the trailer on a level and firm surface.
- ▶ Apply the parking brake (see "5.9.2 Parking brake", pg. 35).
- ▶ Secure the trailer with wheel chocks (see "5.1 Using wheel chocks", pg. 20).
- ▶ Clean the trailer with lots of water and an acid-free and pH-neutral cleaning agent.
- ▶ Maintain a spraying distance of approx. 30 cm when using high-pressure cleaners.
- ▶ Allow the trailer to dry.
- ✓ The trailer is cleaned.
- ▶ Carry out a departure check (see "7.1 Commissioning before each trip", pg. 60).

10.2 Maintenance

⚠ WARNING

Risk of accident and property damage caused by improperly performed or lack of maintenance!

Improperly performed or lack of maintenance work and incorrect replacement parts affect safety.

- ▶ Observe the national accident prevention regulations.
- ▶ Only have necessary maintenance work performed by an authorised specialist workshop.
- ▶ Only use original spare parts.
- ▶ Observe the maintenance instructions of the installed supplied components.

⚠ WARNING

Risk of accident due to instability and rolling away!

Unintentional trailer movements can cause serious injury and property damage.

- ▶ Secure the trailer against rolling away by applying the parking brake.
- ▶ Use the wheel chocks to prevent the trailer from rolling away.
- ▶ Park the trailer on a solid surface to avoid sinking in or tipping.
- ▶ Ensure stability when the trailer is unhitched. If necessary, use additional supports.

The aim of maintenance is:

- that the commissioned trailer is kept operating safely and performing properly during use,
- to prevent downtimes,
- to keep the costs of operational readiness reasonable and financially justifiable,
- and to limit unavoidable repair expenditures.

10.2.1 Regular checks and functional testing

To ensure that the trailer is in proper operating condition, the safety-related equipment must be checked regularly for proper function, its effectiveness must be ensured and the recurring inspections must be performed.

- ▶ Prior to starting each trip, perform a departure check (see "7.1 Commissioning before each trip", pg. 60).
- ▶ Perform legally prescribed general inspections punctually.
- ▶ Observe the intervals and instructions for testing and maintenance of the supplied components (e.g. axles) contained within the respective supplied operating instructions.
- ▶ Report any detected safety defects:
 - Take the trailer out of operation if operational safety is not ensured.
 - When there is a change of shift, inform the colleague starting the next shift about observed defects and implemented measures.
- ▶ Perform the following checks and functional testing at the intervals prescribed:

Daily, or before every journey

Component	Inspection
Rear underrun protection/side collision protection	▶ Visually inspect for wear, damage and proper attachment.
Compressed air tank	▶ Actuate the water drain valve (see "5.8 Draining the compressed air tanks", pg. 33).

Component	Inspection
Lighting equipment	▶ Visually inspect to make sure it is working properly.
Hydraulic rear width expansion (optional)	Visually inspect for wear, damage, leakage and proper attachment, perform a functional test on the pump.
Coupling ring	▶ Visual check for wear, damage and proper attachment.
Draw fork	▶ Visual check for wear, damage and proper attachment. ▶ Lubricate the spring bolt on the base shoe.
Drawbar wale	▶ Visual check for wear, damage and proper attachment.

Weekly

Component	Inspection
Compressed air tank	▶ Perform a visual inspection for wear and damage.
Tyres	▶ Check the tread depth and tyre pressure

- ▶ Go to an authorised specialist workshop if defects have been found.

10.2.2 Maintenance intervals for the authorised specialist workshop

Assembly group	Maintenance work	Monthly	Every six months	Yearly
Wheels and tyres (see "10.2.4 Wheels and tyres", pg. 81)	<ul style="list-style-type: none"> ▶ Check the tightening torques of the wheel nuts. Additionally: For the first time after 50 and 100 km or after every wheel change ▶ Check the tyres and the tyre inflation pressure. 		X	
Axle and suspension (see "10.2.5 Axle and suspension", pg. 81)	<ul style="list-style-type: none"> ▶ Check the tightening torque of the fixing bolts. ▶ Observe the maintenance instructions from the axle manufacturer. 	X		
Brake system (see "10.2.6 Brake system", pg. 82)	<ul style="list-style-type: none"> ▶ Check the screw connections (additionally: after the first trip). ▶ Check brake pad wear ▶ Check the brake discs/brake drums for damage and cracks. 			X
Compressed air system (see "5.8 Draining the compressed air tanks", pg. 33)	<ul style="list-style-type: none"> ▶ Check the compressed air tank. ▶ Check the compressed air connections. ▶ Check the compressed air lines. 			X
Lubrication points (see "10.2.7 Lubricating the trailer", pg. 83)	<ul style="list-style-type: none"> ▶ Top up the grease on all the lubrication points. ▶ Pay attention to the lubrication points shown in the applicable operating instructions. 			X
Electrical equipment (see "10.2.8 Electrical equipment", pg. 83)	<ul style="list-style-type: none"> ▶ Check all electrical components for proper function. 			X
Contour marking (see "10.2.9 Contour marking", pg. 83)	<ul style="list-style-type: none"> ▶ Check the contour markings for completeness and legibility. 	X		
Bolted connections (see "10.2.10 Bolted connections", pg. 83)	<ul style="list-style-type: none"> ▶ Perform a visual inspection for wear and damage. 			X
Load securing	<ul style="list-style-type: none"> ▶ Perform a visual inspection for wear and damage. 			X

10.2.3 Maintenance intervals for the driver

Assembly group	Maintenance work	Monthly	Every six months	Yearly
Wheels and tyres (see "10.2.4 Wheels and tyres", pg. 81)	<ul style="list-style-type: none"> ▶ Check the tightening torques of the wheel nuts. ▶ Check the tyres and the tyre inflation pressure. 			X
Axle and suspension (see "10.2.5 Axle and suspension", pg. 81)	<ul style="list-style-type: none"> ▶ Observe the maintenance instructions from the axle manufacturer. 	X		
Compressed air system (see "5.8 Draining the compressed air tanks", pg. 33)	<ul style="list-style-type: none"> ▶ Check the compressed air tank. ▶ Check the compressed air connections. 			X
Contour marking (see "10.2.9 Contour marking", pg. 83)	<ul style="list-style-type: none"> ▶ Check the contour markings for completeness and legibility. 	X		
Load securing (see "10.2.11 Load securing", pg. 83)	<ul style="list-style-type: none"> ▶ Perform a visual inspection for wear and damage. 			X
Lubrication points (see "10.2.7 Lubricating the trailer", pg. 83)	<ul style="list-style-type: none"> ▶ Top up the grease on all the lubrication points. ▶ Pay attention to the lubrication points shown in the applicable operating instructions. 			X

10.2.4 Wheels and tyres

- ▶ Check the tightening torques of the wheel nuts. The tightening torque depends on the rim design.
- ▶ Observe the supplier documentation.
- ▶ Perform a visual inspection for wear and damage:
 - Check the tread depth of the tyres regularly.
 - Check the tyres for damage.
- ▶ Check the tyre inflation pressure regularly according to the manufacturer specifications and correct if necessary. The tyre inflation pressure depends on the technical characteristics of the tyre.
- ▶ Observe the supplier documentation.

- ▶ Drive only with approved rim and tyre combinations.
- ▶ Observe the seasonal tyres (summer or winter tyres) for the trailer.

10.2.5 Axle and suspension

- ▶ Perform a visual inspection for wear and damage.
- ▶ Have defective or damaged components replaced.
- ▶ Check the tightening torque of the fixing bolts.
- ▶ Observe the maintenance instructions from the axle manufacturer.

10.2.6 Brake system

⚠ WARNING

Risk of accident caused by defective brakes!

A failure or defect of the brake system can lead to serious accidents.

- ▶ Drive only with properly functioning brake system.
- ▶ In case of defect or wear, park the trailer immediately.
- ▶ Abnormalities or malfunctions of the brake system must be immediately repaired by an authorised specialist workshop.
- ▶ Have the trailer towed if necessary.

Checking the axles/brake system

- ▶ Check all bolted connections on new trailers after repairs, after the first trip or at the latest after 1,000 km.
- ▶ Retighten bolted connections with the tightening torques specified by the manufacturer.
- ▶ Observe the maintenance instructions of the installed supplied components.
- ▶ Immediately consult an authorised specialist workshop if there are defects with the brake or ABS/EBS system (see "9.2 Fixing braking abnormalities", pg. 74).

Servicing the diagnostics connection for the EBS brake system

The EBS diagnostics connection is established using the EBS plug connector (ISO 7638, 7-pin) at the front of the vehicle. The diagnosis may only be performed by an authorised specialist workshop.

- ▶ Keep the protective caps closed to prevent soiling.

Brake pad conditioning

⚠ WARNING

Risk of accident due to rear-end collision!

When performing braking for conditioning, other road users can collide with the rear of your trailer and seriously injure themselves.

- ▶ When performing the braking for conditioning, make sure that other road users are not endangered by this action.

In order to obtain maximum performance and a long service life for the brake pads, the brake pads must be in an optimum condition. It may be necessary to condition the brake pad for this optimum condition due to underloading, weather conditions and when the trailer has been stood idle for a long period of time.

- ▶ As a preventative measure, perform the conditioning by braking accordingly.
- ▶ Procedure:
 - Strong braking and/or dragging brakes
 - Then allow the brake pads to cool down
 - Repeat in a cyclical loading mode
- ▶ Observe other technical information from the axle manufacturer regarding the topic of "Conditioning".

Obtaining the reference braking values

The reference braking values are used as the default for the legal brake tests. The reference braking values for every current trailer can be obtained on the KRONE website (see "12.2 Customer service and support", pg. 88).

10.2.7 Lubricating the trailer

NOTE

Material damage caused by dry lubrication points!

Too little or a lack of grease can result in damage to moving parts.

- ▶ Lubricate the trailer regularly.

- ▶ Top up the grease on all the lubrication points.
- ▶ Lubricate moving parts on the trailer superstructure (e.g. door locks, hinges) as needed.
- ▶ Lubricate the grease nipple on the turnframe every 8,000 – 10,000 km.
- ▶ Also observe the enclosed supplier documentation.

10.2.8 Electrical equipment

- ▶ Perform a visual check of the electrical connections for the lighting and ABS/EBS for wear and damage.
- ▶ Perform a visual check of the lighting and signalling systems.
- ▶ Have defective electrical components replaced by an authorised specialist workshop.
- ▶ Only have work on the electrical equipment performed by trained electricians, or by personnel trained especially for the purpose, in accordance with all applicable safety rules and regulations.

10.2.9 Contour marking

- ▶ Perform a regular visual check of the contour markings.
- ▶ Pay attention to damage, soiling and visibility.
- ▶ Have defective or damaged contour markings replaced.

10.2.10 Bolted connections

- ▶ Check bolted connections regularly for settling signs.
- ▶ Replace defective bolted connections.

- ▶ Observe the instructions about bolted connections in the supplier documentation.

10.2.11 Load securing

- ▶ Perform a visual inspection for wear and damage.
- ▶ Have defective or damaged components replaced.

10.2.12 Coupling ring

⚠ WARNING

Risk of accident caused by wear!

A worn coupling ring can cause the trailer to tear off while driving and result in serious injuries and material damage.

- ▶ Check the wear on the coupling ring regularly.
- ▶ Worn coupling rings must be replaced by an authorised specialist workshop.
- ▶ Check the coupling ring for wear and damage.

INFO

Observe the maintenance instructions, dimensions and values of the coupling ring manufacturer. Worn coupling rings must be checked and replaced by an authorised specialist workshop.

- ▶ Check the mounting and tighten the fastening bolts if required.
- ▶ Lubricate the coupling ring as needed.

10.2.13 Tail lift batteries

⚠ WARNING

Risk of explosion due to released gases!

Gases released from the battery can explode, thereby injuring people and causing material damage.

- ▶ Turn off the tractor unit's motor while servicing the battery.
- ▶ Avoid fire, naked lights, sparks, and smoking near the batteries.

⚠ CAUTION

Risk of injury due to battery acid!

- ▶ Wear protective gloves and glasses when servicing batteries.
- ▶ Immediately rinse off acid splashes with clear water.

INFO

Be mindful of the capacity when replacing batteries. The capacity must match the generator output of the tractor unit. The battery capacity is indicated on the housing.

- ▶ Regularly check the charge state.
- ▶ Avoid damage due to deep discharging when the batteries are under high burden. If necessary, use an external charger.
- ▶ Regularly check the acid condition.

10.3 Repair

⚠ DANGER

Risk of accident due to unintended vehicle movements!

Unintended vehicle movements can cause serious injury.

- ▶ Use wheel chocks to prevent the trailer from rolling away.
- ▶ Park the trailer on solid and level ground to avoid sinking in or tipping.
- ▶ During maintenance and repair work, observe the stability of the trailer.
- ▶ Observe the applicable national accident prevention regulations.

⚠ CAUTION

Risk of injury due to unexpected component movements!

Pneumatically or electrically driven components may move unexpectedly and injure people.

- ▶ Fully depressurise the pneumatic system and disconnect the electrical connections before beginning maintenance work. Ensure that the system cannot be switched on again.

⚠ WARNING

Risk of accident and material damage caused by improperly performed troubleshooting and repair work!

Improperly performed troubleshooting and repair work affect safety and may lead to serious injuries and property damage.

- ▶ Only have necessary repair work performed by an authorised specialist workshop.
- ▶ Only use original spare parts and spare parts authorised by KRONE.
- ▶ Observe the instructions concerning troubleshooting issued by the suppliers of the installed components.
- ▶ Verify functionality after installing/repairing components.

Repair work includes the replacement and the repair of components and is only required when components are damaged by wear or other external circumstances.

The following applies to the specialist workshop:

- The necessary repair work must be performed professionally, according to the rules of engineering and in accordance with the applicable regulations.
- Do not repair worn or damaged components using a makeshift repair.
- Only use original or approved spare parts for repairs (see "12.1 Spare parts", pg. 88).

- Always replace any removed seals with new seals.
- Welding work on the frame, chassis and on bearing parts may only be performed after consultation with KRONE customer service and KRONE construction.

Replacing defective bulbs

WARNING

Risk of accident due to defective bulbs!

Defective bulbs cause poor visibility and insufficient perception by third parties. There is a risk of traffic accidents.

- ▶ Replace defective bulbs immediately.

Defective bulbs can be replaced by the driver.

- Use similarly rated bulbs as replacements.
- Switch off the lighting system when changing bulbs to prevent a short circuit.
- Check the fuses of the lighting system if necessary.
- Observe the supplier documentation when replacing bulbs.
- If there are frequently occurring defects, have the electrical system checked out by an authorised specialist workshop.

11 Decommissioning

11.1 Temporary decommissioning

NOTE

Material damage caused by long downtimes!

If the decommissioning lasts for several months, the tyres can be damaged by storage deterioration.

- ▶ Move the trailer once a month to prevent the tyres from deteriorating during storage.

The following measures need to be taken to temporarily decommission the trailer:

- ▶ Clean the trailer.
- ▶ Drive the trailer onto firm and level ground.
- ▶ If necessary, protect the trailer from excess water and snow loads.
- ▶ Apply the parking brake (see "5.9.2 Parking brake", pg. 35).
- ▶ Secure the trailer against rolling away (see "5.1 Using wheel chocks", pg. 20).
- ▶ Drain the brake system (see "5.8 Draining the compressed air tanks", pg. 33).
- ▶ Before the start of the frosty period, fill up the brake lines with antifreeze (see "5.8 Draining the compressed air tanks", pg. 33).
- ▶ Close off the coupling heads for the supply and control connections separately with protective caps.
- ▶ Observe the instructions for decommissioning the installed supplied components.
- ✓ The trailer is temporarily decommissioned.

11.2 Recommissioning

⚠ WARNING

Risk of accident and material damage due to lack of checks!

After longer downtimes, the wear condition of the KRONE trailer's axle can change. Operating the axle when not in perfect technical condition can lead to serious accidents or material damage.

- ▶ Perform a component check before driving for the first time.
- ▶ Fix any detected faults before driving off.
- ▶ Serious faults must be repaired by an authorised specialist workshop.

To recommission the trailer after temporary decommissioning, the following measures must be taken:

- ▶ Perform a general visual inspection.
- ▶ Check the entire lighting system.
- ▶ Check the tyre inflation pressure, age and condition of the tyres.
- ▶ Check the function of the brake system.
- ▶ Check the function of the air suspension.
- ▶ Grease the lubrication points.
- ▶ Carry out a departure check (see "7.1 Commissioning before each trip", pg. 60).
- ▶ Check the coupling heads for the supply and control connections for cleanliness and functioning seals.
- ▶ Observe the other applicable operating instructions for recommissioning the installed supplied components.
- ✓ The trailer has been put back into operation again.

11.3 Final decommissioning and disposal

NOTE

Environmental damage due to improper disposal!

Improperly disconnecting and disposing of operating materials along with electric, pneumatic and hydraulic parts may harm the environment.

- ▶ Ensure that they are disposed of properly by a specialist company
- ▶ Observe the national and local regulations for the disposal.

After the final decommissioning, the trailer must be disposed of properly. In doing so, the electrical, pneumatic and hydraulic components must be disposed of separately.

To fully decommission the trailer and to dispose of it properly, the following actions must be performed:

- ▶ Ensure that the disposal is done properly and in an environmentally sound way.
- ▶ Have the trailer disposed of properly by a specialist company.
- ▶ Observe the national and local regulations for the disposal.
- ▶ Observe the instructions for decommissioning issued by the suppliers of the installed components.
- ✓ The trailer is permanently taken out of operation and disposed of.

12 Spare parts and customer service

12.1 Spare parts

NOTE

Property damage caused by incorrect spare parts!

The use of non-approved or incorrect spare parts affects safety and can result in voiding of the operating permit.

- ▶ Only use original spare parts.

The original spare parts are regularly checked for safety and functionality. The use of original spare parts guarantees road and operating safety and the operating permit is retained.

- ▶ When ordering spare parts, indicate the vehicle ID number.

You can order spare parts by phone under +49 (0) 59 51 / 209-302 or from the KRONE website. An electronic spare parts catalogue is available on the website: www.krone-trailer.com

12.2 Customer service and support

The customer service department at Fahrzeugwerk Bernard KRONE GmbH & Co. KG can be reached using the following contact data:

Customer Service

Telephone: +49 (0) 59 51 / 209-320

Fax: +49 (0) 59 51 / 209-367

Internet: www.krone-trailer.com

email: kd.nfz@krone.de

Spare parts

Telephone: +49 (0) 59 51 / 209-302

Fax: +49 (0) 59 51 / 209-238

Internet: www.krone-trailer.com

email: Ersatzteile.nfz@krone.de

Fahrzeugwerk Bernard KRONE
GmbH & Co. KG
Bernard-Krone-Straße 1
D-49757 Werlte

13 Technical data

13.1 Dimensions and weights

The technical data can vary depending on the vehicle equipment. A list of the technical data for all variants is not possible here. The vehicle-specific technical data is noted in the vehicle documents. The measurements and weights in the following table refer to the basic vehicle model.

Building material turnframe trailer (AZP eL41-BS)

Dimensions and weights	
Permitted total weight	18,000 kg
Axle load	18,000 kg
Dead weight	approx. 3,850 kg
Unladen ride height	1,290 mm
Wheelbase	4,870 mm
Front wall height	1,200 mm
Board wall height	1,000 mm
Load compartment length	7,100 mm
Load compartment width	2,480 mm
Total length (up to the centre of the coupling ring)	9,020 mm

Building material central axle trailer (AZP eL41-BS)

Dimensions and weights	
Permitted total weight	18,000 kg
Axle load	18,000 kg
Dead weight	approx. 3,910 kg
Unladen ride height	1,275 mm
Wheelbase	1,310 mm
Front wall height	1,200 mm
Board wall height	1,000 mm
Load compartment length	6,500 mm
Load compartment width	2,480 mm
Total length (up to the centre of the coupling ring)	8,205 mm

Further information can be found on our website www.krone-trailer.com.

13.2 Plugs and socket pin assignments

13.2.1 Connector

Turnframe trailers are equipped with plugs.

The function and arrangement of the contact pins in the plug are identical to the arrangement of the contact openings in the socket.

13.2.2 Socket S (white) ISO 3731, 7-pin




Fig. 13-1: Socket ISO S 3731, 7-pin

Contact no.	Colour	Function
1/31	White	Ground
2/58L	Black	Unassigned
3/L	Yellow	Reversing light
4/54	Red	Permanent power (+24 V)
5/R	Green	Steering axle lock (optional)
6/58R	Brown	Lift axles (optional)
7/54G	Blue	Rear fog light

13.2.3 Socket N (black) ISO 1185, 7-pin




Fig. 13-2: Socket ISO N 1185, 7-pin

Contact no.	Colour	Function
1/31	White	Ground
2/58L	Black	Rear, boundary and licence plate lights, left-hand side
3/L	Yellow	Direction indicator, left
4/54	Red	Brake light
5/R	Green	Direction indicator right
6/58R	Brown	Rear, boundary and licence plate lights, right-hand side
7/54G	Blue	Unassigned

Contact no.	Colour	Function
1	Yellow	Direction indicator, left
2	Green	Direction indicator right
3	Blue	Rear fog light
4	White	Ground
5	Black	Rear, boundary and licence plate lights, left-hand side
6	Brown	Rear, boundary and licence plate lights, right-hand side
7	Red	Brake light
8	Pink	Reversing light
9	Orange	Permanent power (+24 V)
10		Steering axle lock (optional)
11		Unassigned
12	Grey	Lift axles (optional)
13		Unassigned
14		Unassigned
15		Unassigned

13.2.4 Socket ISO 12098, 15-pin




Fig. 13-3: Socket ISO12098, 15-pin

Index

A

Air suspension	39
Electronic	40
Axle	81

B

Blind couplings	32
Board wall	53
Brake system	34, 82
Reference braking values	82
Braking abnormalities	75

C

Cleaning	78
Climbing aid	42
Commissioning	
Before each trip	60
Initial commissioning	19
Compressed air connection	30
Compressed air tank	33
Connections	
Brake	30
EBS	30
Electrical system	30
Contour marking	83
Coupling heads	
C-coupling heads	31, 32
Duo-Matic	31
Standard	30
Customer Service	88

D

Danger area	12
Decommissioning	
Disposal	87
Recommissioning	86
Temporary	86
Delivery	19
Depots	49
Dimensions	89
Disposal	87
Drawbar wale	28

E

EBS	34
Diagnostics connection	82
Edge protectors	58
Emergency release device	37
Environmental hazards	15

F

Form-fitting	68
Front wall (mobile)	57
Front wall depot	58

H

Hitching	61, 62
----------------	--------

I

Instandsetzung	84
Intended use	10

L

Landing leg winch	21
Lashing material	67
Load securing	14, 66
Form-fitting	68
Multi Fix system	71
Multi Safe system	69
Tension chains	68
Lubrication points	83

M		S	
Maintenance	79	Safety	10
Authorised specialist workshop	80	Service brake	35
Driver	81	Side collision protection.....	43
Maintenance and repair.....	77	Socket	
Malfunctions	73	Socket ISO N 1185, 7-pin	90
Manoeuvring.....	63	Socket ISO S 3731, 7-pin	89
Multi Fix system.....	71	Socket ISO12098, 15-pin.....	90
Multi Flex chain adapter	70	Spare parts.....	88
Multi Flex Flat chain adapter	70	Spare wheel	44
Multi Lash lashing rings	69	Storage box	47
Multi Rail lashing rail	72	Symbols.....	8
Multi Safe system	69	T	
Multi Fix system.....	71	Technical data	89
Multi Flex chain adapter.....	70	Tension chains	68
Multi Flex Flat chain adapter.....	70	Troubleshooting.....	73
Multi Lash lashing rings	69	U	
Multi Rail lashing rail.....	72	Unhitch	62, 63
Multilock external frame.....	69	V	
Multilock external frame	69	Vehicle identification.....	7
P		W	
Park	64	Warnings	10
Parking brake	35	Warranty.....	15
Emergency release device	37	Weights	89
Personal protective equipment.....	12	Wheel chocks	
Post	53	Place	21
R		With anti-theft device	20
Ramp adjustment	39	With spring clip mount	20
Rear brace.....	23	Without anti-theft device	20
Rear wall	55	Wheels	81
Recommissioning	86		

FAHRZEUGWERK BERNARD KRONE GMBH & CO. KG

Bernard-Krone-Straße 1, 49757 Werlte, GERMANY

Phone: +49 (0) 5951 / 209-0, Fax: +49 (0) 5951 / 209-98268

info.nfz@krone.de, www.krone-trailer.com

07/2019